

ULTRIX

Guide to Configuration File Maintenance

Order Number: AA-ME90D-TE
December 1991

Product Version: ULTRIX Version 4.2A or higher

This manual describes how to build and maintain the system configuration file and how to build a new kernel.

digital equipment corporation
Maynard, Massachusetts

Restricted Rights: Use, duplication, or disclosure by the U.S. Government is subject to restrictions as set forth in subparagraph (c) (1) (ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013.

© Digital Equipment Corporation 1989, 1990, 1991
All rights reserved.

The information in this document is subject to change without notice and should not be construed as a commitment by Digital Equipment Corporation. Digital Equipment Corporation assumes no responsibility for any errors that may appear in this document.

The software described in this document is furnished under a license and may be used or copied only in accordance with the terms of such license.

No responsibility is assumed for the use or reliability of software on equipment that is not supplied by Digital or its affiliated companies.

The following are trademarks of Digital Equipment Corporation:

ALL-IN-1, Bookreader, CDA, DDIF, DDIS, DEC, DECnet, DECstation, DECsystem, DECUS, DECwindows, DTIF, MASSBUS, MicroVAX, Q-bus, ULTRIX, ULTRIX Mail Connection, ULTRIX Worksystem Software, UNIBUS, VAX, VAXstation, VMS, VT, XUI, and the DIGITAL logo.

UNIX is a registered trademark of UNIX System Laboratories, Inc.

Contents

About This Manual

Audience	v
Organization	v
Related Documents	v
Conventions	vi

1 Configuration Files

1.1 The System Configuration File	1-1
1.2 The Generic System Configuration File	1-2
1.2.1 Global Definitions	1-2
1.2.2 Options Definitions	1-7
1.2.3 The makeoptions Definitions for RISC Processors	1-8
1.2.4 System Image Definitions	1-9
1.2.5 Device Definitions	1-10
1.2.5.1 Adapter Specifications	1-11
1.2.5.2 Master Specifications	1-11
1.2.5.3 Controller Specifications	1-12
1.2.5.4 Device Specifications	1-14
1.2.5.5 Disk Specifications	1-15
1.2.6 Pseudodevice Definitions	1-16
1.3 Generic Configuration Files	1-17

2 Building the Kernel

2.1 When To Build a New Kernel	2-1
2.2 Building a Kernel Automatically	2-2
2.2.1 Using the doconfig Program	2-2
2.2.2 Testing the New Kernel	2-5
2.3 Building a New Kernel Manually	2-6

2.3.1	Edit the Configuration File	2-6
2.3.2	Run the config Utility	2-7
2.3.3	Define the Code Dependencies	2-7
2.3.4	Compile and Load the Binary Files	2-8
2.3.5	Boot the New Kernel	2-9
2.4	Building a Kernel After a Capacity Upgrade Installation	2-9
2.5	How to Recover When a New Kernel Fails to Boot	2-10

A Device Mnemonics

Index

Examples

1-1:	Configuration File for VAX Processors	1-17
1-2:	Configuration File for RISC Processors	1-27
2-1:	Sample doconfig Execution	2-4

Tables

A-1:	Devices Supported by MAKEDEV	A-2
------	------------------------------------	-----

About This Manual

This guide provides information on how to maintain the system configuration file and how to build a new kernel system image. This guide also explains how to build a new kernel automatically or manually.

Audience

This is written for the person responsible for managing and maintaining an ULTRIX system. It assumes that this individual is familiar with ULTRIX commands, the system configuration, the system's controller and drive unit number assignments and naming conventions, and an editor such as `vi` or `ed`. You do not need to be a programmer to use this guide.

Organization

This manual consists of two chapters, one appendix, and an index:

- Chapter 1. Configuration Files
Explains the content and format of the configuration files and provides sample generic configuration files.
- Chapter 2. Building the Kernel
Describes how to build a kernel either automatically or manually and explains how to build a new kernel after a capacity upgrade installation.
- Appendix A. Device Mnemonics
Lists the supported device mnemonics and explains how to obtain detailed reference page information on devices.

Related Documents

You should have the hardware documentation for your system and peripherals.

Conventions

The following conventions are used in this manual:

<code>%</code>	The default user prompt is your system name followed by a right angle bracket. In this manual, a percent sign (<code>%</code>) is used to represent this prompt.
<code>#</code>	A number sign is the default superuser prompt.
UPPERCASE lowercase	The operating system differentiates between lowercase and uppercase characters. Literal strings that appear in text, examples, syntax descriptions, and function definitions must be typed exactly as shown.
macro	In text, this typeface is used to introduce new terms.
<code>% cat</code>	A regular constant-width typeface is used for code examples, system prompts in interactive examples, and names of commands and other literal strings in text. A bold constant-width typeface is used for typed user input in interactive examples and for routines in function definitions.
<i>filename</i>	In examples, syntax descriptions, and function definitions, this typeface indicates variable values.
cat file	In syntax definitions, a bold sans serif typeface is used for literal strings and a sloping sans serif typeface is used for variable values.
...	In syntax descriptions and function definitions, a horizontal ellipsis indicates that the preceding item can be repeated one or more times.
<code>cat(1)</code>	A cross-reference to a reference page include the appropriate section number in parentheses. For example, a reference to <code>cat(1)</code> indicates that you can find the material on the <code>cat</code> command in Section 1 of the reference pages.

This chapter explains the contents and format of the configuration files for VAX and RISC processors. The chapter provides a sample generic configuration file in each case to illustrate how specific information defines the hardware, software, and system parameters.

In addition to the information contained in this chapter, the following information will help you to understand the software and hardware components of your system:

- Section 4 of the *ULTRIX Reference Pages* contains definitions of supported devices, special files, interfaces, and system utilities involved in system configuration. For example, see `autoconf(4)` for a description of the configuration diagnostics utility; `rz(4)` for a description of the SCSI disk driver; `ra(4)` for a description of the MSCP disk driver; `ln(4)` for the description of the Ethernet interface; and `tz(4)` for a description of the SCSI tape driver.
- Section 8 of the *ULTRIX Reference Pages* contains definitions of various system utilities used during the configuration process. For example, see `config(8)` and `MAKEDEV(8)`.
- Appendix A provides information on the `MAKEDEV` script and lists the names of the device mnemonics supported by `MAKEDEV`.

1.1 The System Configuration File

The system configuration file describes how you want the configuration software to build the kernel. It identifies all of the device driver source code that needs to be compiled into the kernel, as well as a number of system parameters that affect how the kernel operates.

The kernel is the system image that controls system scheduling, memory management, input and output services, device management, and organization of the file systems. Provided you have enough disk space, you can build more than one kernel.

- For VAX processors, the system configuration file resides in `/usr/sys/conf/vax` and has the same name as the system name (in uppercase letters) that you defined during the installation procedure. For example, if you named your system `tucson` during the installation procedure, then the system configuration file name will be `/usr/sys/conf/vax/TUCSON`.
- For RISC processors, the system configuration file resides in `/usr/sys/conf/mips` and has the same name as the system name (in uppercase letters) that you defined during the installation procedure. For example, if you named your system `tucson` during the installation procedure, then the system configuration file name will be `/usr/sys/conf/mips/TUCSON`.

1.2 The Generic System Configuration File

The installation software provides you with a generic system configuration file that you can use as a template to build or tailor other configuration files.

- For VAX processors, the generic configuration file is `/usr/sys/conf/vax/GENERIC`.
- For RISC processors, the generic configuration file is `/usr/sys/conf/mips/GENERIC`.

The generic system configuration file, like all system configuration files, consists of sections. The sections for the generic system configuration file are:

- Global definitions
- Options definitions
- Makeoptions definitions
- System image definitions
- Device definitions
- Pseudodevice definitions

Note

Some generic system configuration file sections may not be relevant to your processor. For example, the makeoptions definitions apply only to RISC processors. Similarly, some of the system parameters discussed later in this section will not appear in your configuration file. These parameters, as well as some of the arguments to the parameters, are described here because they may be used in some system configuration files.

1.2.1 Global Definitions

The global definitions parameters apply to all the kernels generated by the configuration file. Each global definition appears on a separate line in the configuration file.

Each line represents a tunable system parameter and begins with one of these keywords:

```
machine
cpu
ident
timezone
maxusers
maxuprc
maxuva
physmem
bufcache
swapfrag
maxtsiz
maxdsiz
maxssiz
smmin
smmax
smseg
smsmat
```

```
smbrok  
processors  
scs_sysid
```

The following paragraphs display the syntax and describe how and when to use each parameter:

machine *type*

This parameter defines the hardware; the argument *type* must be `vax` for VAX machines and `mips` for RISC machines. For example, to define a VAX processor to the configuration file, enter:

```
machine vax
```

cpu "*type*"

This parameter defines the processor; the argument *type* must be enclosed in quotes. For example, to define a DECstation 3100 CPU, enter:

```
cpu "DS3100"
```

For VAX processors, the generic configuration file lists the CPU types by processor class. The configuration file lists the processors by CPU type because, in some cases, the configuration software assigns an equivalence name to the processor name. For instance, the MVAX entry applies to the MicroVAX II and VAXstation 2000 processors. The VAX3600 entry in the GENERIC configuration file applies to all of the MicroVAX 3000, VAX 3000, and VAXserver 3000 families of processors.

If you know your processor class, you can use the processor class for your configuration file entry. If you do not know your processor class, you can use the exact processor name. For example, you can use one of the following processor names:

```
DS3100  
DS5000  
DS5400  
DS5500  
DS5800  
VAX8800  
VAX8820  
VAX8700  
VAX8600  
VAX8550  
VAX8530  
VAX8500  
VAX8350  
VAX8300  
VAX8200  
VAX6400  
VAX6210  
VAX6220  
VAX3600  
VAX3500  
VAX3400  
VAX3300  
VAX785  
VAX780  
VAX750  
VAX420  
MVAX
```

You can specify more than one *cpu type* entry in the configuration file for a kernel that can be booted on multiple CPUs. However, if you specify more than one *cpu type* entry, your system builds more capabilities than it needs. The result in most cases is that your kernel requires more memory than a kernel for a single processor requires. Under these conditions, your system may page and swap frequently during daily operations, which affects system performance.

ident name

This parameter defines the host machine for which you are creating the configuration file. The *name* argument is the system name that you specified during the installation procedure. Enter the name in uppercase letters. For example, the following defines the host machine TUCSON:

```
ident TUCSON
```

This parameter ensures that all host-specific source code is compiled during the actual configuration process.

timezone number dst x

This parameter defines time zone information for your site. The installation procedure enters this value to your system configuration file according to information you supply during the installation or when you register a diskless client. The *number* argument identifies your time zone, measured by the number of hours west of Greenwich Mean Time. For example, Eastern Standard Time is five hours west of Greenwich Mean Time, and Pacific Standard Time is eight hours west. Negative numbers indicate hours east of GMT. The generic configuration file time zone entry is set to Eastern Daylight Savings Time (the entry is *timezone 5 dst*).

The argument *dst* indicates daylight savings time. During the installation procedure, you can include a number (*x*) to request a particular daylight savings time correction algorithm. The values are as follows:

- 1 United States (the default value)
- 2 Australia
- 3 Western Europe
- 4 Central Europe
- 5 Eastern Europe

maxusers number

This parameter defines the maximum number of simultaneously active users allowed on your system. Make the *number* argument equal to or greater than the maximum number of users allowed by your license agreement.

The number in this field is used in system algorithms when the system is built to size a number of system data structures and to determine the amount of space allocated to system tables. One such table is the system process table, which is used to determine how many active processes can be running at one time.

maxuprc number

This parameter defines the the maximum number of processes one user can run simultaneously. The default *maxuprc* entry is 50.

maxuva *num*

This parameter defines the maximum aggregate size of user virtual address space in megabytes allowed by the system. The default value is 256 megabytes. This parameter does not apply to RISC processors.

physmem *number*

This parameter defines an estimate of the amount of physical memory currently in the system, in megabytes. This *number* argument is not used to limit the amount of memory; it is used by the system to size the system page table. Consequently, it should be greater than or equal to the amount of physical memory in the system.

bufcache *percent*

This parameter defines the amount of physical memory that is to be allocated for use by the file system buffer cache. The *percent* argument must be greater than or equal to 10 but less than 100. The specified percentage of the actual amount of physical memory found at boot time is allocated for this purpose; this memory is never used for other purposes.

At boot time, if there is not enough memory to satisfy minimum system needs, the percentage is automatically reduced and a diagnostic message is issued.

Because the buffer cache places a demand on the system page table, correct operation requires a sensible value for *physmem* as described previously. At boot time, if the system page table is too small to support the buffer cache, this percentage is automatically reduced and a diagnostic message is issued.

Note

The amount of physical memory used for the buffer cache is never used for program execution. A high percentage may help data-intensive applications but cause problems with applications that require the majority of memory for program execution.

The following example shows the format of the buffer cache parameter:

```
bufcache          25
```

swapfrag *number*

The system satisfies requests for additional swap space using the value *swapfrag*. A process is granted *number* 512-byte blocks of swap space each time the process requests swap space.

When the *swapfrag* number increases, the swap space wastage also increases. The minimum value of *number* should be at least 16. The default value of *number* is 64. The *number* value must be a power of 2.

maxtsiz *num*

This parameter defines the largest text segment in megabytes allowed by the system.

- For VAX processors, the default value is 12 megabytes.
- For RISC processors, the default value is 32 megabytes.

maxdsiz *num*

This parameter defines the largest data segment, in megabytes, allowed by the system. The default value is 32 megabytes.

Note

You must use `maxdsiz` to increase the data segment size, and `maxsiz` to increase the stack segment size. The parameters `dmmax` and `dmmin` are no longer supported.

`maxssiz num`

This parameter defines the largest stack segment in megabytes allowed by the system. The default value is 32 megabytes.

`smmin num`

- For VAX processors, this parameter defines the minimum number of 512-byte pages of virtual memory at which a shared memory segment may be sized. The default for `smmin` is 0 blocks.
- For RISC processors, this parameter defines the minimum number of 4096-byte pages of virtual memory at which a shared memory segment may be sized. The default for `smmin` is 0 pages.

For more information, see `shmget(2)` in the *ULTRIX Reference Pages*.

`smmax num`

- For VAX processors, this parameter defines the maximum number of 512-byte pages of virtual memory at which a shared memory segment may be sized. The default for `smmax` is 256 blocks (128 kilobytes).
- For RISC processors, this parameter defines the maximum number of 4096-byte pages of virtual memory at which a shared memory segment may be sized. The default for `smmax` is 32 pages (128 kilobytes).

For more information, see `shmget(2)` in the *ULTRIX Reference Pages*.

`smseg num`

This parameter defines the maximum number of shared memory segments per process. The default value is 6. For more information, see `shmop(2)` in the *ULTRIX Reference Pages*.

`smsmat num`

This parameter defines the highest attachable address, in megabytes, for shared memory segments.

- For VAX processors, the default value is `MAXDSIZE`.
- For RISC processors, the default value is 0. Although the parameter is valid, be aware that this check is not made.

For more information, see `shmop(2)` in the *ULTRIX Reference Pages*.

`smbrk num`

- For VAX processors, this parameter defines the default spacing between the end of a private data space of a process and the beginning of its shared data space in 512-byte pages of virtual memory. This value is important, because once a process attaches shared memory, private data cannot grow past the beginning of shared data. The default for `smbrk` is 64 pages (32 kilobytes).

- For RISC processors, this parameter defines the default spacing between the end of a private data space of a process and the beginning of its shared data space in 4096-byte pages of virtual memory. This value is important because, once a process attaches shared memory, private data cannot grow past the beginning of shared data. The default for `smbrok` is 10 pages (40 kilobytes).

For more information on shared memory operations, see `shmop(2)` in the *ULTRIX Reference Pages*.

`processors` *num*

This parameter defines the number of processors in the system.

`scs_sysid` *number*

This parameter identifies each host uniquely on the CI star cluster to the SCS subsystem. The *number* argument must be a unique identifier for each host. At installation, the system automatically generates this number and puts it in the configuration file. If the system does not detect a CI at installation, it provides a default value of 1.

1.2.2 Options Definitions

The options definitions parameters specify optional code to be compiled into the system. It is best to leave the options as they appear in the generic configuration file. However, you can remove any of the options (with the exception of the `EMULFLT` option) if your system is short on physical memory space.

The syntax for options definitions is:

`options` *optionlist*

The possible values for *optionlist* are:

EMULFLT

This option enables emulation of the floating point instruction set if it is not already present in the hardware. The `EMULFLT` option must not be deleted from the configuration file. If this option is deleted, unpredictable system behavior can result.

FULLDUMPS

This option enables full dump support.

INET

This option provides Internet communication protocols. The `inet` pseudodevice must also be listed in the Pseudodevice Definitions section of the file.

LAT

This option allows you to access your machine from a local area terminal server on the Ethernet. The `lta` and `lat` pseudodevices must also be listed in the Pseudodevice Definitions section of the file.

DECNET

If the DECnet layered product is installed, this option must be set. The `decnet` pseudodevice must also be listed in the Pseudodevice Definitions section of the file.

QUOTA

This option allows disk quotas to be set.

SYS_TRACE

This option enables the system call tracing capability. The `sys_trace` pseudodevice must also be listed in the Pseudodevice Definitions section of the file.

DLI

This option allows the `mop_mom` program to be active. The `mop_mom` command is usually included in the `/etc/rc.local` file as a background task to cause `mop_mom` to listen for down-line and up-line load requests over the network. The `dli` pseudodevice must also be set.

SYS_TPATH

This option enables the trusted path mechanism. The `sys_tpath` pseudodevice must also be set.

RPC

This option allows RPC-based applications. It is required when the NFS option is specified. The `rpc` pseudodevice must also be set.

NFS

This option allows you to access the NFS protocol. It requires that the RPC option be listed and that the `nfs` pseudodevice also be listed in the Pseudodevices Section of the file.

UFS

This option enables the standard, local file system. If you do not use the NFS option, the UFS option must be set. If you do not specify this option, the system will be considered diskless. The `ufs` pseudodevice must also be set.

AUDIT [= *number*]

This option loads the optional audit subsystem files into the kernel. To specify the base size of the audit buffers in bytes, use the *number* option. The default base size of the audit buffers is 16 kilobytes.

SMP

This option allows multiples processors to run. If you list this option on a single processor, there is a performance penalty. Do not use this option with a single processor.

1.2.3 The makeoptions Definitions for RISC Processors

You can specify one makeoptions definition in the generic configuration file for RISC processors. The format of the makeoptions definition is as follows:

```
makeoptions OPTION_NAME="argument"
```

The *OPTION_NAME* variable must be in uppercase letters. The *argument* variable must be placed within quotation marks ("). The *OPTION_NAME* and *argument* variables are separated by an equal sign (=). The makeoptions definition follows:

```
ENDIAN="-EL"
```

This definition specifies the byte order within words used by the processor, and must be "-EL."

1.2.4 System Image Definitions

There is one system definition in the generic configuration file. However, you can change the definition or add more lines to the configuration file you are building to indicate that you want to generate more than one kernel. For each kernel you wish to generate, specify one line that begins with the keyword `config`. Each line is used to define the root device, the swap area or areas, the dump area, and the argument processing area for system calls.

The general format for the system image definition is as follows:

```
config filename configuration-clauses
```

The *filename* argument is the name to be assigned to the file constituting the compiled kernel, or system image. The installation procedure assigns the name `vmunix`. The *configuration-clauses* define the devices for the root file system, for the paging and swapping area, and for crash dumps. The *configuration-clauses* keywords are `root`, `swap`, and `dumps`. The syntax and descriptions of these keywords are as follows:

`root [on] device`

The installation procedure assigns partition `a` of the system disk to the root file system. You can change this assignment by editing the configuration file. For diskless clients, this entry is set to `root on ln0`.

Some configuration file entries for the system image definition are as follows:

```
config    vmunix    root on ln0
config    vmunixa   root on rz0a
```

The first entry specifies that the root file system resides on the remote (network) boot device. You must use this entry for diskless clients. The second entry specifies that the root file system resides on partition `a` of the local boot device, `rz` drive `0`.

`swap [on] device [and device] [size x] [boot]`

The first *device* argument specifies the device and partition that you want the system to use for a paging and swapping area. The installation procedure assigns partition `b` of the system disk for the paging and swapping area. You can change this assignment by editing the configuration file.

The second *device* argument enables you to add another partition, so the kernel interleaves paging and swapping between the two partitions. To specify a second paging and swapping area, use the `and` clause with a device, a logical unit, and a partition name.

Use the `size` clause to specify a nonstandard partition size for one or more swap areas. The value of `x` represents the number of 512-byte sectors. A size larger than the associated disk partition is trimmed to the partition size. The default swap device is partition `b` of the device where the root is located.

If you specify `swap on boot`, the `a` partition of the booted device becomes the root, and swap space is assumed to be the `b` partition of the same device.

Example configuration file entries are as follows:

```
config vmunix swap on boot
config vmunixa root on ln0 swap on rz0b
config vmunixb root on rz0a swap on rz0b
```

In the first example, the root file system is on partition `a` of the local boot device, and partition `b` of the same device becomes the swap space. In the second example, the root file system resides on the remote (network) boot device, but the system swaps on partition `b` of the local disk at drive 0. In the last example, the root file system is on partition `a` of the local boot device (rz0), and the system swaps on partition `b` of the same device.

You can also swap between two disks. For example, if you specify a swap on both rz0b and rz1b, the system can swap on partition `b` of either disks. Note that you must add an entry to the `/etc/fstab` file to specify the second disk for the `mount` and `fsck` commands.

For diskless systems, if the swap file is remote, then you do not have to specify a swap device.

Avoid selecting partition `a` of any disk for use as the swap partition. If partition table information was defined for a disk and swapping occurs on the `a` partition, the information is destroyed and data is lost.

`dumps [on] device`

The *device* argument specifies the partition and the device where crash dumps are to be stored. The device that is specified must be on the same controller as the boot device. The default dump device is the first swap device configured.

Usually, this entry is unnecessary in a diskless environment, because the `dms` setup process specifies using the `mop_mom` command for dumping. For a description of this command, see `mop_mom(8)` in the *ULTRIX Reference Pages*. For more information on diskless environments, see the *Guide to Sharing Software on a Local Area Network*.

1.2.5 Device Definitions

The Device Definitions section of the configuration file contains descriptions of each current or planned device on the system. You need to add definitions for devices that were not on the system at installation time. You may also want to delete device definitions for devices that have been removed from the hardware configuration.

Each line of this section of the file begins with one of the following keywords:

<code>adapter</code>	Identifies a physical connection to a system bus such as VAXBI, MASSBUS, Q-bus, UNIBUS, MSI, IBUS, or CI.
<code>master</code>	A MASSBUS tape controller.
<code>controller</code>	Identifies either a physical or a logical connection with one or more slaves attached to it. Some examples are <code>uda</code> , <code>kdb</code> , <code>hsc</code> , and <code>uq</code> .
<code>device</code>	An autonomous device that connects directly to a Q-bus, or to a UNIBUS, MASSBUS, IBUS, or VAXBI adapter (as opposed to a disk, for example, that connects through a disk controller).

disk A disk drive connected to either a master or a controller.

tape A tape drive connected to either a master or a controller.

The format of the information required for each of these types of devices varies, as described in the following sections.

1.2.5.1 Adapter Specifications

The following list provides the format in the configuration file for the VAXBI, MASSBUS, UNIBUS, MSI, CI, IBUS, and Q-bus adapters:

- For VAXBI adapters:
 adapter vaxb*n* at nexus?
 The *n* is the unit number of the adapter. The question mark (?) allows the system to pick the appropriate NEXUS for you.
- For MASSBUS adapters:
 adapter mba*n* at nexus?
 The *n* is the unit number of the adapter. The question mark (?) allows the system to pick the appropriate NEXUS for you.
- For IBUS adapters:
 adapter ibus*n* at nexus?
 The *n* is the unit number of the adapter. The question mark (?) allows the system to pick the appropriate NEXUS for you.
- For UNIBUS and Q-bus adapters (Q-bus adapters are specific to MicroVAX-type and VAXstation-type processors):
 adapter uba0 at nexus?
 The question mark (?) allows the system to pick the appropriate NEXUS for you.
- For MSI adapters:
 adapter msi0 at nexus?
 The question mark (?) allows the system to pick the appropriate NEXUS for you.
- For CI adapters:
 adapter ci0 at nexus?
 adapter ci0 at vaxbi?
 The question mark (?) allows the system to pick the appropriate NEXUS or VAXBI for you.

1.2.5.2 Master Specifications

MASSBUS tape drives must be attached to a master controller. The format for specifying a master controller is:

master *devname* at mba*m* drive*n*

dev The name of the tape device, such as ht0.

m The MASSBUS adapter number.

n The drive number.

For example:

```
master    ht0            at mba?        drive?
tape      tu0            at ht0         slave 0
tape      tu1            at ht0         slave 1
```

1.2.5.3 Controller Specifications

This section contains examples of the specifications for the various device controllers. The controller examples are for MSCP, TMSCP, and SCSI devices. This section also defines the format for specifying tape-to-disk interface controllers.

The specifications for MSCP disk controllers are as follows:

- For UNIBUS or Q-bus:

```
controller uda0 at uba0
controller uq0 at uda0 csr 0172150 vector uqintr
disk ra0 at uq0 drive 0
disk ra1 at uq0 drive 1
disk ra2 at uq0 drive 2
disk ra3 at uq0 drive 3
```

- For VAXBI:

```
controller kdb0 at vaxbi0 node?
controller uq0 at kdb0 vector uqintr
disk ra0 at uq0 drive 0
disk ra1 at uq0 drive 1
disk ra2 at uq0 drive 2
disk ra3 at uq0 drive 3
controller aiol at vaxbi? node?
controller bvpssp0 at aiol vector bvpsspintr
disk ra0 at bvpssp0 drive 0
```

- For VAX CI/HSC:

```
adapter ci0 at nexus?
adapter ci0 at vaxbi? node?
controller hsc0 at ci0 cinode0
disk ra0 at hsc0 drive0
```

- For MSI bus:

```
adapter msi0 at nexus?
controller dssc0 at msi0 msinode 0
disk ra0 at dssc0 drive 0
```

- For XMI:

```
controller kdm0 at xmi0 node?
controller uq0 at kdm0 vector uqintr
disk ra0 at uq0 drive 0
disk ra1 at uq0 drive 1
disk ra2 at uq0 drive 2
disk ra3 at uq0 drive 3
disk ra4 at uq0 drive 4
disk ra5 at uq0 drive 5
disk ra6 at uq0 drive 6
disk ra7 at uq0 drive 7
```

The specifications for TMSCP tape controllers are as follows:

- For UNIBUS or Q-bus:

```
controller klesiu0 at uba0
controller uq0 at klesiu0 csr 0174500 vector uqintr
tape tms0 at uq0 drive 0
```

- For VAXBI:

```
controller klesib0 at vaxbi0 node 0
controller uq0 at klesib0 vector uqintr
tape tms0 at uq0 drive 0
controller aie0 at vaxbi? node?
controller bvpssp0 at aie0 vector bvpsspintr
tape tms0 at bvpssp0 drive 0
```

- For MSI Bus:

```
adapter msi0 at nexus?
controller dssc0 at msi0 msinode0
tape tms0 at dssc0 drive 0
```

- For VAX CI/HSC:

```
adapter ci0 at nexus?
adapter ci0 at vaxbi? node?
controller hsc0 at ci0 cinode0
tape tms0 at hsc0 drive 0
```

- For XMI:

```
controller kdm0 at xmi0 node?
controller uq0 at kdm0 vector uqintr
tape tms0 at uq0 drive 0
tape tms1 at uq0 drive 1
```

There are three types of SCSI controllers: scsi, sii, and asc. The generic specifications for SCSI controllers for both tape and disks are as follows:

- For disks:

```
adapter      uba0 at nexus?
controller   scsi0 at uba0  csr 0x200c0080 vector szintr
controller   scsi0 at uba0  csr 0x200c0080 vector szintr
disk         rz1 at scsi0   drive 1
disk         rz2 at scsi0   drive 2
disk         rz9 at scsi1   drive 1
disk         rz10 at scsi1  drive 2
```

```
controller   sii0 at ibus?  vector sii_intr
disk         rz0 at sii0    drive 0
disk         rz1 at sii0    drive 1
disk         rz2 at sii0    drive 2
disk         rz3 at sii0    drive 3
disk         rz4 at sii0    drive 4
```

```
controller   asc0 at ibus?  vector ascintr
controller   asc1 at ibus?  vector ascintr
controller   asc2 at ibus?  vector ascintr
disk         rz1 at asc0    drive 1
disk         rz2 at asc0    drive 2
disk         rz9 at asc1    drive 1
disk         rz13 at asc1   drive 5
disk         rz17 at asc2   drive 1
disk         rz20 at asc2   drive 4
```

- For tapes:

```

adapter      uba0 at nexus?
controller   scsi0 at uba0  csr 0x200c0080 vector szintr
controller   scsi0 at uba0  csr 0x200c0080 vector szintr
tape         tz1 at scsi0   drive 1
tape         tz2 at scsi0   drive 2
tape         tz9 at scsi1   drive 1
tape         tz10 at scsi1  drive 2

```

```

controller   sii0 at ibus?  vector sii_intr
tape         tz0 at sii0   drive 0
tape         tz1 at sii0   drive 1
tape         tz2 at sii0   drive 2

```

```

controller   asc0 at ibus?  vector ascintr
controller   asc1 at ibus?  vector ascintr
controller   asc2 at ibus?  vector ascintr
tape         tz1 at asc0   drive 1
tape         tz2 at asc0   drive 2
tape         tz9 at asc1   drive 1
tape         tz13 at asc1  drive 5
tape         tz17 at asc2  drive 1
tape         tz20 at asc2  drive 4

```

The following specification describes the format for the magnetic tape interface (ts) and the disk interface:

```

controller dev at condev [ csr n ] vector vec
tape unit at dev drive n

```

dev The device name and logical unit number of the controller.

condev The name and logical unit number of the device to which the controller is connected.

n For the controller, *n* represents the 16-bit octal address of the control status register for the device. This entry is not needed for the VAXBI. For the tape, *n* represents the logical name of the tape unit.

unit The unit number of the tape drive.

vec The address of any interrupt vector for the controller.

This example shows a sample entry for a TU80 or TSV05 (for MicroVAX systems) magnetic tape interface:

```

controller   zs0 at uba0  csr 0172520 vector tsintr
tape         ts0 at zs0  drive 0

```

1.2.5.4 Device Specifications

The format for hardware classified as a device is as follows:

```

device dev condev [ csr n ] [ flags f ] vector vl ...

```

Use tab characters to indicate continuation lines, if needed.

dev The device name and logical unit number of the device.

- condev* The name and logical unit number of the adapter or controller to which the device is connected.
- n* The octal address of the control status register for the device. The `csr n` option is not needed for VAXBI devices. A number used to convey information about the device to the device driver. The only flags for Digital-supported devices are for line printers and communications multiplexers.
- f* The default page width for all Digital line printers is 132 columns. To change the page width, use `flags f`, where *f* is a decimal number giving the desired width in columns. For example, to change to 80 columns, enter `flags 80`.
- The DH, DZ, DMB, DHU, DMF, and DMZ communications multiplexers accept a hexadecimal flag value to specify any lines that are to be treated as hardwired, with carrier always present. The DHV-11, DZQ, and DZV serve the same function as the Q-bus. The format of the hexadecimal number is `0xnn`, where *nn* is a hexadecimal number consisting of digits ranging from 0-9, a-f.
- Because bits are numbered from right to left, setting bit 0 of the flag indicates that `tty00` is hardwired; setting bit 1 of the flag indicates that `tty01` is hardwired, and so forth. The following example shows that `tty02` is hardwired with carrier always present: `flags 0x04`.
- vl...* The names of interrupt vector routines for the device driver.

The following example shows a sample device specification for the DEUNA 10-MB Ethernet interface:

```
device de0 at uba0 csr 0174510 vector deintr
```

The following example shows a sample device specification for a DZ-11 communications multiplexer:

```
device dz0 at uba0 csr 0160100 flags 0xff vector dzrint dzxint
```

The following example shows a sample device specification for a DMB32 communications controller device:

```
device dmb0 at vaxbi2 node3 flags 0x00ff vector dmbsint dmbaint dmblint
```

1.2.5.5 Disk Specifications

The format for specifying disks is as follows:

```
disk dev at condev drive n
```

- dev* The device name and logical unit number of the disk.
- condev* The name and logical unit number of the adapter or controller to which the disk is connected.
- n* The physical unit number of the disk. If your disk is an MSCP (RA) unit, or if your disk is on a MASSBUS device, you can specify a question mark (?) for *n*. A question mark (?) allows the system to assign the physical number to the disk for you.

Here is an example of a device specification for MSCP disks:

```
disk ra0 at uq0 drive 0
```

1.2.6 Pseudodevice Definitions

A pseudodevice is an operating system component for which there is no associated hardware; for example, a pseudoterminal or one of the various supported protocols. The configuration file contains pseudodevice definitions to allow the operating system to recognize these components.

Each pseudodevice definition line in the configuration file defines a driver for a particular pseudodevice. Each pseudodevice definition line begins with the keyword `pseudodevice`, followed by the pseudodevice name. The format is as follows:

```
pseudo-device name [num]
```

The *name* variable defines the name of the pseudodevice. The *num* argument specifies a number that is different from the default value.

The possible values for *name* and *num* are:

- | | |
|------------------------|---|
| <code>pty</code> | Pseudoterminal support. The default is 32. Specify <i>num</i> in increments of 16 if more than 32 pseudoterminals are defined in your configuration file. For example, to assign 58 pseudoterminals, specify <code>pseudo-device pty 64</code> . |
| <code>inet</code> | DARPA Internet protocols. |
| <code>loop</code> | Network loopback interface. |
| <code>presto</code> | Enables kernel support for the ULTRIX Prestoserve product on the DS5500. This pseudodevice is automatically placed in the configuration file during the installation procedure. |
| <code>ether</code> | 10-MB Ethernets. |
| <code>lat</code> | Local area terminal (LAT) protocols. If you list this name, you must also list the <code>lta</code> pseudodevice name. |
| <code>lta</code> | Pseudoterminal driver. The default is 16. Specify <i>num</i> in increments of 16 if more than 16 pseudoterminal drivers are defined in the configuration file. For example, to assign 30 pseudoterminals, specify <code>pseudo-device lta 32</code> . If you list this name, you must also list the <code>lat</code> pseudodevice name. |
| <code>decnet</code> | DECNET support – this is required only when the DECNET layered product is installed. |
| <code>sys_trace</code> | Support of the system call trace capability. |
| <code>dli</code> | DLI support of <code>mop_mom</code> activity. |
| <code>bsc</code> | Support of 2780/3780 emulation. To work, the <code>dpv0</code> or <code>dup0</code> devices must be defined in the configuration file as described in Section 1.2.5. (These devices apply to VAX systems only.) |

rpc Remote Procedure Call facility.

nfs Network File System (NFS) protocol support.

ufs Local file system support.

scsnet Systems Communications Services (SCS) network interface driver. For more information, see `scs(4)` in the *ULTRIX Reference Pages*.

audit This is required when specifying AUDIT support. Provides the generation of the file `'hostname' /audit .h`, which causes the appropriate files to be rebuilt when a new system is generated.

sys_tpath This is required when specifying SYS_TPATH support. Provides support for trusted path mechanism.

1.3 Generic Configuration Files

The following examples show typical generic configuration files. Example 1-1 illustrates a VAX configuration. Example 1-2 illustrates a RISC configuration. The generic configuration file supplied with your system may differ from the ones shown here.

Example 1-1: Configuration File for VAX Processors

```
#
# @(#)GENERIC 3.2 (ULTRIX) 6/6/90
# GENERIC VAX
#
machine vax
cpu "VAX8800"
cpu "VAX8600"
cpu "VAX8200"
cpu "VAX6400"
cpu "VAX6200"
cpu "VAX785"
cpu "VAX780"
cpu "VAX750"
cpu "VAX3600"
cpu "VAX420"
cpu "VAX60"
cpu "MVAX"
ident GENERIC
timezone 5 dst
maxusers 2
maxuprc 10
physmem 6
processors 1
scs_sysid 32
options QUOTA
options INET
options UFS
options NFS
options RPC
options EMULFLT
options SCA_SEVERITY ="SCA_LEVEL5"

config vmunix swap on boot
```

Example 1-1: (continued)

config dlvmunix root on boot

#all the adapters and adapter-like items

```

adapter            xmi0        at    nexus?
adapter            vaxbi0     at    nexus?
adapter            vaxbi1     at    nexus?
adapter            vaxbi2     at    nexus?
adapter            vaxbi3     at    nexus?
adapter            vaxbi4     at    nexus?
adapter            vaxbi5     at    nexus?
adapter            vaxbi11    at    nexus?
adapter            vaxbi12    at    nexus?
adapter            vaxbi13    at    nexus?
adapter            vaxbi14    at    nexus?
adapter            mba0        at    nexus?
adapter            mba1        at    nexus?
adapter            mba2        at    nexus?
adapter            mba3        at    nexus?
adapter            uba0        at    nexus?
adapter            uba1        at    nexus?
adapter            uba2        at    nexus?
adapter            uba3        at    nexus?
adapter            uba4        at    nexus?
adapter            uba5        at    nexus?
adapter            uba6        at    nexus?
adapter            ibus0      at    nexus?
adapter            ibus1      at    nexus?
adapter            ibus2      at    nexus?
adapter            ibus3      at    nexus?
adapter            ibus4      at    nexus?
adapter            ibus5      at    nexus?
adapter            ibus7      at    nexus?
adapter            msi0        at    nexus?
adapter            ci0        at    nexus?
adapter            ci0        at    vaxbi?    node?

```

#all the controllers and controller-like items

```

controller        hsc0        at    ci0            cinode 0
controller        hsc1        at    ci0            cinode 1
controller        hsc2        at    ci0            cinode 2
controller        hsc3        at    ci0            cinode 3
controller        hsc4        at    ci0            cinode 4
controller        hsc5        at    ci0            cinode 5
controller        hsc6        at    ci0            cinode 6
controller        hsc7        at    ci0            cinode 7
controller        hsc8        at    ci0            cinode 8
controller        hsc9        at    ci0            cinode 9
controller        hsc10      at    ci0            cinode 10
controller        hsc11      at    ci0            cinode 11
controller        hsc12      at    ci0            cinode 12
controller        hsc13      at    ci0            cinode 13
controller        hsc14      at    ci0            cinode 14
controller        hsc15      at    ci0            cinode 15
controller        dssc0      at    msi0           msinode 0
controller        dssc1      at    msi0           msinode 1
controller        dssc2      at    msi0           msinode 2
controller        dssc3      at    msi0           msinode 3
controller        dssc4      at    msi0           msinode 4
controller        dssc5      at    msi0           msinode 5
controller        dssc6      at    msi0           msinode 6
controller        dssc7      at    msi0           msinode 7
controller        aio0        at    vaxbi?        node?
controller        aio1        at    vaxbi?        node?

```

Example 1-1: (continued)

controller	aie0	at vaxbi?	node?
controller	aie1	at vaxbi?	node?
controller	aie2	at vaxbi?	node?
controller	aie3	at vaxbi?	node?
controller	aie4	at vaxbi?	node?
controller	kdb0	at vaxbi?	node?
controller	kdb1	at vaxbi?	node?
controller	kdb2	at vaxbi?	node?
controller	kdb3	at vaxbi?	node?
controller	kdb4	at vaxbi?	node?
controller	kdb5	at vaxbi?	node?
controller	kdb6	at vaxbi?	node?
controller	kdb7	at vaxbi?	node?
controller	kdb8	at vaxbi?	node?
controller	kdb9	at vaxbi?	node?
controller	kdb10	at vaxbi?	node?
controller	kdb11	at vaxbi?	node?
controller	kdm0	at xmi?	node?
controller	kdm1	at xmi?	node?
controller	klesib0	at vaxbi?	node?
controller	klesib1	at vaxbi?	node?
controller	klesib2	at vaxbi?	node?
controller	klesib3	at vaxbi?	node?
controller	uda0	at uba?	
controller	uda1	at uba?	
controller	uda2	at uba?	
controller	uda3	at uba?	
controller	klesiu0	at uba?	
controller	klesiu1	at uba?	
controller	klesiu2	at uba?	
controller	klesiu3	at uba?	
controller	bvpssp0	at aio0	vector bvpsspintr
controller	bvpssp1	at aio1	vector bvpsspintr
controller	bvpssp2	at aie0	vector bvpsspintr
controller	bvpssp3	at aie1	vector bvpsspintr
controller	uq0	at uda0	csr 0172150 vector uqintr
controller	uq1	at uda1	csr 0172150 vector uqintr
controller	uq2	at uda2	csr 0172150 vector uqintr
controller	uq3	at uda3	csr 0172150 vector uqintr
controller	uq4	at kdb0	vector uqintr
controller	uq5	at kdb1	vector uqintr
controller	uq6	at kdb2	vector uqintr
controller	uq7	at kdb3	vector uqintr
controller	uq8	at kdb4	vector uqintr
controller	uq9	at kdb5	vector uqintr
controller	uq10	at kdb6	vector uqintr
controller	uq11	at kdb7	vector uqintr
controller	uq12	at kdb8	vector uqintr
controller	uq13	at kdb9	vector uqintr
controller	uq14	at kdb10	vector uqintr
controller	uq15	at kdb11	vector uqintr
controller	uq16	at klesiu0	csr 0174500 vector uqintr
controller	uq17	at klesiu1	csr 0174500 vector uqintr
controller	uq18	at klesiu2	csr 0174500 vector uqintr
controller	uq19	at klesiu3	csr 0174500 vector uqintr
controller	uq20	at klesib0	vector uqintr
controller	uq21	at klesib1	vector uqintr
controller	uq22	at klesib2	vector uqintr
controller	uq23	at klesib3	vector uqintr
controller	uq24	at kdm0	vector uqintr
controller	uq25	at kdm1	vector uqintr
controller	hk0	at uba?	csr 0177440 vector rkintr
controller	sdc0	at uba0	csr 0x200c0000 vector sdintr

Example 1-1: (continued)

controller	h10	at uba?	csr 0174400	vector rlintr
controller	zs0	at uba?	csr 0172520	vector tsintr
controller	stc0	at uba0	csr 0x200c0080	vector stintr
controller	scsi0	at uba0	csr 0x200c0080	vector szintr
controller	scsi1	at uba0	csr 0x200c0180	vector szintr
controller	sii0	at ibus?		vector sii_intr

#all the disks

disk	rd0	at sdc0	drive 0
disk	rd1	at sdc0	drive 1
disk	rx2	at sdc0	drive 2
disk	r10	at h10	drive 0
disk	r11	at h10	drive 1
disk	r12	at h10	drive 2
disk	r13	at h10	drive 3
disk	hp0	at mba?	drive 0
disk	hp1	at mba?	drive 1
disk	hp2	at mba?	drive 2
disk	hp3	at mba?	drive 3
disk	hp4	at mba?	drive 4
disk	hp5	at mba?	drive 5
disk	hp6	at mba?	drive 6
disk	hp7	at mba?	drive 7
disk	rk0	at hk0	drive 0
disk	rk1	at hk0	drive 1
disk	rk2	at hk0	drive 2
disk	rk3	at hk0	drive 3
disk	rk4	at hk0	drive 4
disk	rk5	at hk0	drive 5
disk	rk6	at hk0	drive 6
disk	rk7	at hk0	drive 7
disk	ra0	at mscp	drive 0
disk	ra1	at mscp	drive 1
disk	ra2	at mscp	drive 2
disk	ra3	at mscp	drive 3
disk	ra4	at mscp	drive 4
disk	ra5	at mscp	drive 5
disk	ra6	at mscp	drive 6
disk	ra7	at mscp	drive 7
disk	ra8	at mscp	drive 8
disk	ra9	at mscp	drive 9
disk	ra10	at mscp	drive 10
disk	ra11	at mscp	drive 11
disk	ra12	at mscp	drive 12
disk	ra13	at mscp	drive 13
disk	ra14	at mscp	drive 14
disk	ra15	at mscp	drive 15
disk	ra16	at mscp	drive 16
disk	ra17	at mscp	drive 17
disk	ra18	at mscp	drive 18
disk	ra19	at mscp	drive 19
disk	ra20	at mscp	drive 20
disk	ra21	at mscp	drive 21
disk	ra22	at mscp	drive 22
disk	ra23	at mscp	drive 23
disk	ra24	at mscp	drive 24
disk	ra25	at mscp	drive 25
disk	ra26	at mscp	drive 26
disk	ra27	at mscp	drive 27
disk	ra28	at mscp	drive 28
disk	ra29	at mscp	drive 29
disk	ra30	at mscp	drive 30
disk	ra31	at mscp	drive 31

Example 1-1: (continued)

disk	ra32	at mscp	drive 32
disk	ra33	at mscp	drive 33
disk	ra34	at mscp	drive 34
disk	ra35	at mscp	drive 35
disk	ra36	at mscp	drive 36
disk	ra37	at mscp	drive 37
disk	ra38	at mscp	drive 38
disk	ra39	at mscp	drive 39
disk	ra40	at mscp	drive 40
disk	ra41	at mscp	drive 41
disk	ra42	at mscp	drive 42
disk	ra43	at mscp	drive 43
disk	ra44	at mscp	drive 44
disk	ra45	at mscp	drive 45
disk	ra46	at mscp	drive 46
disk	ra47	at mscp	drive 47
disk	ra48	at mscp	drive 48
disk	ra49	at mscp	drive 49
disk	ra50	at mscp	drive 50
disk	ra51	at mscp	drive 51
disk	ra52	at mscp	drive 52
disk	ra53	at mscp	drive 53
disk	ra54	at mscp	drive 54
disk	ra55	at mscp	drive 55
disk	ra56	at mscp	drive 56
disk	ra57	at mscp	drive 57
disk	ra58	at mscp	drive 58
disk	ra59	at mscp	drive 59
disk	ra60	at mscp	drive 60
disk	ra61	at mscp	drive 61
disk	ra62	at mscp	drive 62
disk	ra63	at mscp	drive 63
disk	ra64	at mscp	drive 64
disk	ra65	at mscp	drive 65
disk	ra66	at mscp	drive 66
disk	ra67	at mscp	drive 67
disk	ra68	at mscp	drive 68
disk	ra69	at mscp	drive 69
disk	ra70	at mscp	drive 70
disk	ra71	at mscp	drive 71
disk	ra72	at mscp	drive 72
disk	ra73	at mscp	drive 73
disk	ra74	at mscp	drive 74
disk	ra75	at mscp	drive 75
disk	ra76	at mscp	drive 76
disk	ra77	at mscp	drive 77
disk	ra78	at mscp	drive 78
disk	ra79	at mscp	drive 79
disk	ra80	at mscp	drive 80
disk	ra81	at mscp	drive 81
disk	ra82	at mscp	drive 82
disk	ra83	at mscp	drive 83
disk	ra84	at mscp	drive 84
disk	ra85	at mscp	drive 85
disk	ra86	at mscp	drive 86
disk	ra87	at mscp	drive 87
disk	ra88	at mscp	drive 88
disk	ra89	at mscp	drive 89
disk	ra90	at mscp	drive 90
disk	ra91	at mscp	drive 91
disk	ra92	at mscp	drive 92
disk	ra93	at mscp	drive 93
disk	ra94	at mscp	drive 94

Example 1-1: (continued)

disk	ra95	at mscp	drive 95
disk	ra96	at mscp	drive 96
disk	ra97	at mscp	drive 97
disk	ra98	at mscp	drive 98
disk	ra99	at mscp	drive 99
disk	ra100	at mscp	drive 100
disk	ra101	at mscp	drive 101
disk	ra102	at mscp	drive 102
disk	ra103	at mscp	drive 103
disk	ra104	at mscp	drive 104
disk	ra105	at mscp	drive 105
disk	ra106	at mscp	drive 106
disk	ra107	at mscp	drive 107
disk	ra108	at mscp	drive 108
disk	ra109	at mscp	drive 109
disk	ra110	at mscp	drive 110
disk	ra111	at mscp	drive 111
disk	ra112	at mscp	drive 112
disk	ra113	at mscp	drive 113
disk	ra114	at mscp	drive 114
disk	ra115	at mscp	drive 115
disk	ra116	at mscp	drive 116
disk	ra117	at mscp	drive 117
disk	ra118	at mscp	drive 118
disk	ra119	at mscp	drive 119
disk	ra120	at mscp	drive 120
disk	ra121	at mscp	drive 121
disk	ra122	at mscp	drive 122
disk	ra123	at mscp	drive 123
disk	ra124	at mscp	drive 124
disk	ra125	at mscp	drive 125
disk	ra126	at mscp	drive 126
disk	ra127	at mscp	drive 127
disk	ra128	at mscp	drive 128
disk	ra129	at mscp	drive 129
disk	ra130	at mscp	drive 130
disk	ra131	at mscp	drive 131
disk	ra132	at mscp	drive 132
disk	ra133	at mscp	drive 133
disk	ra134	at mscp	drive 134
disk	ra135	at mscp	drive 135
disk	ra136	at mscp	drive 136
disk	ra137	at mscp	drive 137
disk	ra138	at mscp	drive 138
disk	ra139	at mscp	drive 139
disk	ra140	at mscp	drive 140
disk	ra141	at mscp	drive 141
disk	ra142	at mscp	drive 142
disk	ra143	at mscp	drive 143
disk	ra144	at mscp	drive 144
disk	ra145	at mscp	drive 145
disk	ra146	at mscp	drive 146
disk	ra147	at mscp	drive 147
disk	ra148	at mscp	drive 148
disk	ra149	at mscp	drive 149
disk	ra150	at mscp	drive 150
disk	ra151	at mscp	drive 151
disk	ra152	at mscp	drive 152
disk	ra153	at mscp	drive 153
disk	ra154	at mscp	drive 154
disk	ra155	at mscp	drive 155
disk	ra156	at mscp	drive 156
disk	ra157	at mscp	drive 157

Example 1-1: (continued)

disk	ra158	at mscp	drive 158
disk	ra159	at mscp	drive 159
disk	ra160	at mscp	drive 160
disk	ra161	at mscp	drive 161
disk	ra162	at mscp	drive 162
disk	ra163	at mscp	drive 163
disk	ra164	at mscp	drive 164
disk	ra165	at mscp	drive 165
disk	ra166	at mscp	drive 166
disk	ra167	at mscp	drive 167
disk	ra168	at mscp	drive 168
disk	ra169	at mscp	drive 169
disk	ra170	at mscp	drive 170
disk	ra171	at mscp	drive 171
disk	ra172	at mscp	drive 172
disk	ra173	at mscp	drive 173
disk	ra174	at mscp	drive 174
disk	ra175	at mscp	drive 175
disk	ra176	at mscp	drive 176
disk	ra177	at mscp	drive 177
disk	ra178	at mscp	drive 178
disk	ra179	at mscp	drive 179
disk	ra180	at mscp	drive 180
disk	ra181	at mscp	drive 181
disk	ra182	at mscp	drive 182
disk	ra183	at mscp	drive 183
disk	ra184	at mscp	drive 184
disk	ra185	at mscp	drive 185
disk	ra186	at mscp	drive 186
disk	ra187	at mscp	drive 187
disk	ra188	at mscp	drive 188
disk	ra189	at mscp	drive 189
disk	ra190	at mscp	drive 190
disk	ra191	at mscp	drive 191
disk	ra192	at mscp	drive 192
disk	ra193	at mscp	drive 193
disk	ra194	at mscp	drive 194
disk	ra195	at mscp	drive 195
disk	ra196	at mscp	drive 196
disk	ra197	at mscp	drive 197
disk	ra198	at mscp	drive 198
disk	ra199	at mscp	drive 199
disk	ra200	at mscp	drive 200
disk	ra201	at mscp	drive 201
disk	ra202	at mscp	drive 202
disk	ra203	at mscp	drive 203
disk	ra204	at mscp	drive 204
disk	ra205	at mscp	drive 205
disk	ra206	at mscp	drive 206
disk	ra207	at mscp	drive 207
disk	ra208	at mscp	drive 208
disk	ra209	at mscp	drive 209
disk	ra210	at mscp	drive 210
disk	ra211	at mscp	drive 211
disk	ra212	at mscp	drive 212
disk	ra213	at mscp	drive 213
disk	ra214	at mscp	drive 214
disk	ra215	at mscp	drive 215
disk	ra216	at mscp	drive 216
disk	ra217	at mscp	drive 217
disk	ra218	at mscp	drive 218
disk	ra219	at mscp	drive 219
disk	ra220	at mscp	drive 220

Example 1-1: (continued)

```
disk    ra221    at mscp    drive 221
disk    ra222    at mscp    drive 222
disk    ra223    at mscp    drive 223
disk    ra224    at mscp    drive 224
disk    ra225    at mscp    drive 225
disk    ra226    at mscp    drive 226
disk    ra227    at mscp    drive 227
disk    ra228    at mscp    drive 228
disk    ra229    at mscp    drive 229
disk    ra230    at mscp    drive 230
disk    ra231    at mscp    drive 231
disk    ra232    at mscp    drive 232
disk    ra233    at mscp    drive 233
disk    ra234    at mscp    drive 234
disk    ra235    at mscp    drive 235
disk    ra236    at mscp    drive 236
disk    ra237    at mscp    drive 237
disk    ra238    at mscp    drive 238
disk    ra239    at mscp    drive 239
disk    ra240    at mscp    drive 240
disk    ra241    at mscp    drive 241
disk    ra242    at mscp    drive 242
disk    ra243    at mscp    drive 243
disk    ra244    at mscp    drive 244
disk    ra245    at mscp    drive 245
disk    ra246    at mscp    drive 246
disk    ra247    at mscp    drive 247
disk    ra248    at mscp    drive 248
disk    ra249    at mscp    drive 249
disk    ra250    at mscp    drive 250
disk    ra251    at mscp    drive 251
disk    ra252    at mscp    drive 252
disk    ra253    at mscp    drive 253
disk    ra254    at mscp    drive 254
disk    rz0     at scsi0   drive 0
disk    rz1     at scsi0   drive 1
disk    rz2     at scsi0   drive 2
disk    rz3     at scsi0   drive 3
disk    rz4     at scsi0   drive 4
disk    rz5     at scsi0   drive 5
disk    rz6     at scsi0   drive 6
disk    rz7     at scsi0   drive 7
disk    rz8     at scsi1   drive 0
disk    rz9     at scsi1   drive 1
disk    rz10    at scsi1   drive 2
disk    rz11    at scsi1   drive 3
disk    rz12    at scsi1   drive 4
disk    rz13    at scsi1   drive 5
disk    rz14    at scsi1   drive 6
disk    rz15    at scsi1   drive 7
disk    rz0     at sii0    drive 0
disk    rz1     at sii0    drive 1
disk    rz2     at sii0    drive 2
disk    rz3     at sii0    drive 3
disk    rz4     at sii0    drive 4
disk    rz5     at sii0    drive 5
disk    rz6     at sii0    drive 6
disk    rz7     at sii0    drive 7

#all the tapes
tape    st0     at stc0    drive 0
tape    ts0     at zs0     drive 0
master  ht0     at mba?    drive ?
```

Example 1-1: (continued)

```
tape    tu0      at ht0      slave 0
tape    tu1      at ht0      slave 1
tape    tu2      at ht0      slave 2
tape    tu3      at ht0      slave 3
master  mt0      at mba?    drive ?
tape    mu0      at mt0      slave 0
tape    mu1      at mt0      slave 1
tape    mu2      at mt0      slave 2
tape    mu3      at mt0      slave 3
tape    tms0     at mscp     drive 0
tape    tms1     at mscp     drive 1
tape    tms2     at mscp     drive 2
tape    tms3     at mscp     drive 3
tape    tms4     at mscp     drive 4
tape    tms5     at mscp     drive 5
tape    tms6     at mscp     drive 6
tape    tms7     at mscp     drive 7
tape    tms8     at mscp     drive 8
tape    tms9     at mscp     drive 9
tape    tms10    at mscp     drive 10
tape    tms11    at mscp     drive 11
tape    tms12    at mscp     drive 12
tape    tms13    at mscp     drive 13
tape    tms14    at mscp     drive 14
tape    tms15    at mscp     drive 15
tape    tms16    at mscp     drive 16
tape    tms17    at mscp     drive 17
tape    tms18    at mscp     drive 18
tape    tms19    at mscp     drive 19
tape    tms20    at mscp     drive 20
tape    tms21    at mscp     drive 21
tape    tms22    at mscp     drive 22
tape    tms23    at mscp     drive 23
tape    tms24    at mscp     drive 24
tape    tms25    at mscp     drive 25
tape    tms26    at mscp     drive 26
tape    tms27    at mscp     drive 27
tape    tms28    at mscp     drive 28
tape    tms29    at mscp     drive 29
tape    tms30    at mscp     drive 30
tape    tms31    at mscp     drive 31
tape    tz0      at scsi0    drive 0
tape    tz1      at scsi0    drive 1
tape    tz2      at scsi0    drive 2
tape    tz3      at scsi0    drive 3
tape    tz4      at scsi0    drive 4
tape    tz5      at scsi0    drive 5
tape    tz6      at scsi0    drive 6
tape    tz7      at scsi0    drive 7
tape    tz8      at scsi1    drive 0
tape    tz9      at scsi1    drive 1
tape    tz10     at scsi1    drive 2
tape    tz11     at scsi1    drive 3
tape    tz12     at scsi1    drive 4
tape    tz13     at scsi1    drive 5
tape    tz14     at scsi1    drive 6
tape    tz15     at scsi1    drive 7
```

#all the workstations

```
device qv0 at uba0  csr 0177200 flags 0x0f vector qvkind qvuint
device qd0 at uba0  csr 0177400 flags 0x0f vector qddint qdaint qdiint
device qd1 at uba0  csr 0177402 flags 0x0f vector qddint qdaint qdiint
device sm0 at uba0  csr 0x200f0000 flags 0x0f vector smvint
```

Example 1-1: (continued)

```
device sg0 at uba0  csr 0x3c000000 flags 0x0f vector sgaint sgfint
device fg0 at ibus? flags 0x0f vector fgvint

#all the networks
device   bvpni0   at aie0       vector bvpniintr
device   bvpni1   at aie2       vector bvpniintr
device   bvpni2   at aie3       vector bvpniintr
device   bvpni3   at aie4       vector bvpniintr
device   xna0 at vaxbi? node? vector xnaintr
device   xna1 at vaxbi? node? vector xnaintr
device   xna2 at vaxbi? node? vector xnaintr
device   xna3 at vaxbi? node? vector xnaintr
device   xna4 at xmi?       node? vector xnaintr
device   xna5 at xmi?       node? vector xnaintr
device   xna6 at xmi?       node? vector xnaintr
device   xna7 at xmi?       node? vector xnaintr
device   de0  at uba?       csr 0174510 vector deintr
device   del  at uba?       csr 0174510 vector deintr
device   qe0  at uba0       csr 0174440 vector qeintr
device   qe1  at uba0       csr 0174460 vector qeintr
device   ln0  at ibus?      vector lnintr
```

#all the terminals and printers

```
device fc0  at ibus?  flags 0x0f vector fcxrint
device ss0  at uba?   csr 0x200a0000 flags 0x0f vector ssrnt  sxxint
device sh0  at uba0   csr 0x38000000 flags 0xff vector shrnt  shxint
device lp0  at uba?   csr 0177514  vector lpintr
device dmb0 at vaxbi? node? flags 0xff vector dmbsint dmbaint dmblint
device dmb1 at vaxbi? node? flags 0xff vector dmbsint dmbaint dmblint
device dmb2 at vaxbi? node? flags 0xff vector dmbsint dmbaint dmblint
device dmb3 at vaxbi? node? flags 0xff vector dmbsint dmbaint dmblint
device dmb4 at vaxbi? node? flags 0xff vector dmbsint dmbaint dmblint
device dmb5 at vaxbi? node? flags 0xff vector dmbsint dmbaint dmblint
device dmb6 at vaxbi? node? flags 0xff vector dmbsint dmbaint dmblint
device dmb7 at vaxbi? node? flags 0xff vector dmbsint dmbaint dmblint
device dmb8 at vaxbi? node? flags 0xff vector dmbsint dmbaint dmblint
device dmb9 at vaxbi? node? flags 0xff vector dmbsint dmbaint dmblint
device dmb10 at vaxbi? node? flags 0xff vector dmbsint dmbaint dmblint
device dmb11 at vaxbi? node? flags 0xff vector dmbsint dmbaint dmblint
device dmb12 at vaxbi? node? flags 0xff vector dmbsint dmbaint dmblint
device dmb13 at vaxbi? node? flags 0xff vector dmbsint dmbaint dmblint
device dmb14 at vaxbi? node? flags 0xff vector dmbsint dmbaint dmblint
device dmb15 at vaxbi? node? flags 0xff vector dmbsint dmbaint dmblint
```

#all the pseudo items

```
pseudo-device  pty
pseudo-device  loop
pseudo-device  inet
pseudo-device  ether
pseudo-device  ufs
pseudo-device  nfs
pseudo-device  rpc
pseudo-device  presto
```

Example 1-2: Configuration File for RISC Processors

```
#
# @(#)GENERIC 3.6 (ULTRIX) 6/15/90
# GENERIC RISC
#
machine      mips
cpu         "DS3100"
cpu         "DS5400"
cpu         "DS5500"
cpu         "DS5800"
cpu         "DS5000"
ident       "GENERIC"
timezone    5 dst
maxusers    32
maxuprc     50
physmem     8
processors  1
scs_sysid   1

options     QUOTA
options     INET
options     NFS
options     UFS
options     RPC
options     SYS_TRACE
options     LAT
options     DLI
options     UWS

makeoptions ENDIAN="-EL"

config      vmunix          swap on boot
config      dlgenvmunix    root on ln0
config      dlsgenvmunix   root on ln0 swap on rz0b
config      rzzerovmunix   root on rz0a swap on rz0b

#all the adapters and adapter-like items
adapter     xmi0          at nexus?
adapter     vaxbi0       at nexus?
adapter     vaxbi1       at nexus?
adapter     vaxbi2       at nexus?
adapter     vaxbi3       at nexus?
adapter     vaxbi4       at nexus?
adapter     vaxbi5       at nexus?
adapter     vaxbi11      at nexus?
adapter     vaxbi12      at nexus?
adapter     vaxbi13      at nexus?
adapter     vaxbi14      at nexus?
adapter     uba0         at nexus?
adapter     uba1         at nexus?
adapter     uba2         at nexus?
adapter     uba3         at nexus?
adapter     uba4         at nexus?
adapter     uba5         at nexus?
adapter     uba6         at nexus?
adapter     ibus0        at nexus?
adapter     ibus1        at nexus?
adapter     ibus2        at nexus?
adapter     ibus3        at nexus?
adapter     ibus4        at nexus?
adapter     ibus5        at nexus?
adapter     ibus6        at nexus?
adapter     ibus7        at nexus?
adapter     msi0         at nexus?
```

Example 1-2: (continued)

```

adapter      ci0      at nexus?
adapter      vba0     at nexus?
adapter      vba1     at nexus?
adapter      vba2     at nexus?
adapter      vba3     at nexus?

```

```
#all the controllers and controller-like items
```

```

controller  hsc0      at ci0      cinode 0
controller  hsc1      at ci0      cinode 1
controller  hsc2      at ci0      cinode 2
controller  hsc3      at ci0      cinode 3
controller  hsc4      at ci0      cinode 4
controller  hsc5      at ci0      cinode 5
controller  hsc6      at ci0      cinode 6
controller  hsc7      at ci0      cinode 7
controller  hsc8      at ci0      cinode 8
controller  hsc9      at ci0      cinode 9
controller  hsc10     at ci0      cinode 10
controller  hsc11     at ci0      cinode 11
controller  hsc12     at ci0      cinode 12
controller  hsc13     at ci0      cinode 13
controller  hsc14     at ci0      cinode 14
controller  hsc15     at ci0      cinode 15
controller  aio0      at vaxbi?  node?
controller  aio1      at vaxbi?  node?
controller  aie0      at vaxbi?  node?
controller  aie1      at vaxbi?  node?
controller  aie2      at vaxbi?  node?
controller  aie3      at vaxbi?  node?
controller  aie4      at vaxbi?  node?
controller  kdb0      at vaxbi?  node?
controller  kdb1      at vaxbi?  node?
controller  kdb2      at vaxbi?  node?
controller  kdb3      at vaxbi?  node?
controller  kdb4      at vaxbi?  node?
controller  kdb5      at vaxbi?  node?
controller  kdb6      at vaxbi?  node?
controller  kdb7      at vaxbi?  node?
controller  kdb8      at vaxbi?  node?
controller  kdb9      at vaxbi?  node?
controller  kdb10     at vaxbi?  node?
controller  kdb11     at vaxbi?  node?
controller  klesib0   at vaxbi?  node?
controller  klesib1   at vaxbi?  node?
controller  klesib2   at vaxbi?  node?
controller  klesib3   at vaxbi?  node?
controller  kdm0      at xmi?    node?
controller  kdm1      at xmi?    node?
controller  kdm2      at xmi?    node?
controller  kdm3      at xmi?    node?
controller  uda0      at uba?
controller  uda1      at uba?
controller  uda2      at uba?
controller  uda3      at uba?
controller  klesiu0   at uba?
controller  klesiu1   at uba?
controller  klesiu2   at uba?
controller  klesiu3   at uba?
controller  bvpssp0   at aio0     vector bvpsspintr
controller  bvpssp1   at aio1     vector bvpsspintr
controller  bvpssp2   at aie0     vector bvpsspintr
controller  bvpssp3   at aie1     vector bvpsspintr
controller  uq0at     uda0       csr 0172150 vector uqintr

```

Example 1-2: (continued)

```
controller uq1at uda1      csr 0172150 vector uqintr
controller uq2at uda2      csr 0172150 vector uqintr
controller uq3at uda3      csr 0172150 vector uqintr
controller uq4at kdb0      vector uqintr
controller uq5at kdb1      vector uqintr
controller uq6at kdb2      vector uqintr
controller uq7at kdb3      vector uqintr
controller uq8at kdb4      vector uqintr
controller uq9at kdb5      vector uqintr
controller uq10 at kdb6      vector uqintr
controller uq11 at kdb7      vector uqintr
controller uq12 at kdb8      vector uqintr
controller uq13 at kdb9      vector uqintr
controller uq14 at kdb10     vector uqintr
controller uq15 at kdb11     vector uqintr
controller uq16 at klesiu0    csr 0174500 vector uqintr
controller uq17 at klesiu1    csr 0174500 vector uqintr
controller uq18 at klesiu2    csr 0174500 vector uqintr
controller uq19 at klesiu3    csr 0174500 vector uqintr
controller uq20 at klesib0    vector uqintr
controller uq21 at klesib1    vector uqintr
controller uq22 at klesib2    vector uqintr
controller uq23 at klesib3    vector uqintr
controller uq24 at kdm0      vector uqintr
controller uq25 at kdm1      vector uqintr
controller uq26 at kdm2      vector uqintr
controller uq27 at kdm3      vector uqintr
controller dssc0 at msi0      msinode 0
controller dssc1 at msi0      msinode 1
controller dssc2 at msi0      msinode 2
controller dssc3 at msi0      msinode 3
controller dssc4 at msi0      msinode 4
controller dssc5 at msi0      msinode 5
controller dssc6 at msi0      msinode 6
controller dssc7 at msi0      msinode 7
controller uda0 at uba?
controller uda1 at uba?
controller uda2 at uba?
controller uda3 at uba?
controller klesiu0 at uba?
controller klesiu1 at uba?
controller klesiu2 at uba?
controller klesiu3 at uba?
controller sii0 at ibus?     vector sii_intr
controller asc0 at ibus?     vector ascintr
controller      asc1 at ibus? vector ascintr
controller      asc2 at ibus? vector ascintr
controller asc3 at ibus?     vector ascintr

disk ra0 at mscp drive 0
disk ra1 at mscp drive 1
disk ra2 at mscp drive 2
disk ra3 at mscp drive 3
disk ra4 at mscp drive 4
disk ra5 at mscp drive 5
disk ra6 at mscp drive 6
disk ra7 at mscp drive 7
disk ra8 at mscp drive 8
disk ra9 at mscp drive 9
disk ra10 at mscp drive 10
disk ra11 at mscp drive 11
disk ra12 at mscp drive 12
disk ra13 at mscp drive 13
```

Example 1-2: (continued)

disk	ra14	at mscp	drive 14
disk	ra15	at mscp	drive 15
disk	ra16	at mscp	drive 16
disk	ra17	at mscp	drive 17
disk	ra18	at mscp	drive 18
disk	ra19	at mscp	drive 19
disk	ra20	at mscp	drive 20
disk	ra21	at mscp	drive 21
disk	ra22	at mscp	drive 22
disk	ra23	at mscp	drive 23
disk	ra24	at mscp	drive 24
disk	ra25	at mscp	drive 25
disk	ra26	at mscp	drive 26
disk	ra27	at mscp	drive 27
disk	ra28	at mscp	drive 28
disk	ra29	at mscp	drive 29
disk	ra30	at mscp	drive 30
disk	ra31	at mscp	drive 31
disk	ra32	at mscp	drive 32
disk	ra33	at mscp	drive 33
disk	ra34	at mscp	drive 34
disk	ra35	at mscp	drive 35
disk	ra36	at mscp	drive 36
disk	ra37	at mscp	drive 37
disk	ra38	at mscp	drive 38
disk	ra39	at mscp	drive 39
disk	ra40	at mscp	drive 40
disk	ra41	at mscp	drive 41
disk	ra42	at mscp	drive 42
disk	ra43	at mscp	drive 43
disk	ra44	at mscp	drive 44
disk	ra45	at mscp	drive 45
disk	ra46	at mscp	drive 46
disk	ra47	at mscp	drive 47
disk	ra48	at mscp	drive 48
disk	ra49	at mscp	drive 49
disk	ra50	at mscp	drive 50
disk	ra51	at mscp	drive 51
disk	ra52	at mscp	drive 52
disk	ra53	at mscp	drive 53
disk	ra54	at mscp	drive 54
disk	ra55	at mscp	drive 55
disk	ra56	at mscp	drive 56
disk	ra57	at mscp	drive 57
disk	ra58	at mscp	drive 58
disk	ra59	at mscp	drive 59
disk	ra60	at mscp	drive 60
disk	ra61	at mscp	drive 61
disk	ra62	at mscp	drive 62
disk	ra63	at mscp	drive 63
disk	ra64	at mscp	drive 64
disk	ra65	at mscp	drive 65
disk	ra66	at mscp	drive 66
disk	ra67	at mscp	drive 67
disk	ra68	at mscp	drive 68
disk	ra69	at mscp	drive 69
disk	ra70	at mscp	drive 70
disk	ra71	at mscp	drive 71
disk	ra72	at mscp	drive 72
disk	ra73	at mscp	drive 73
disk	ra74	at mscp	drive 74
disk	ra75	at mscp	drive 75
disk	ra76	at mscp	drive 76

Example 1-2: (continued)

```
disk    ra77    at mscp    drive 77
disk    ra78    at mscp    drive 78
disk    ra79    at mscp    drive 79
disk    ra80    at mscp    drive 80
disk    ra81    at mscp    drive 81
disk    ra82    at mscp    drive 82
disk    ra83    at mscp    drive 83
disk    ra84    at mscp    drive 84
disk    ra85    at mscp    drive 85
disk    ra86    at mscp    drive 86
disk    ra87    at mscp    drive 87
disk    ra88    at mscp    drive 88
disk    ra89    at mscp    drive 89
disk    ra90    at mscp    drive 90
disk    ra91    at mscp    drive 91
disk    ra92    at mscp    drive 92
disk    ra93    at mscp    drive 93
disk    ra94    at mscp    drive 94
disk    ra95    at mscp    drive 95
disk    ra96    at mscp    drive 96
disk    ra97    at mscp    drive 97
disk    ra98    at mscp    drive 98
disk    ra99    at mscp    drive 99
disk    ra100   at mscp    drive 100
disk    ra101   at mscp    drive 101
disk    ra102   at mscp    drive 102
disk    ra103   at mscp    drive 103
disk    ra104   at mscp    drive 104
disk    ra105   at mscp    drive 105
disk    ra106   at mscp    drive 106
disk    ra107   at mscp    drive 107
disk    ra108   at mscp    drive 108
disk    ra109   at mscp    drive 109
disk    ra110   at mscp    drive 110
disk    ra111   at mscp    drive 111
disk    ra112   at mscp    drive 112
disk    ra113   at mscp    drive 113
disk    ra114   at mscp    drive 114
disk    ra115   at mscp    drive 115
disk    ra116   at mscp    drive 116
disk    ra117   at mscp    drive 117
disk    ra118   at mscp    drive 118
disk    ra119   at mscp    drive 119
disk    ra120   at mscp    drive 120
disk    ra121   at mscp    drive 121
disk    ra122   at mscp    drive 122
disk    ra123   at mscp    drive 123
disk    ra124   at mscp    drive 124
disk    ra125   at mscp    drive 125
disk    ra126   at mscp    drive 126
disk    ra127   at mscp    drive 127
disk    ra128   at mscp    drive 128
disk    ra129   at mscp    drive 129
disk    ra130   at mscp    drive 130
disk    ra131   at mscp    drive 131
disk    ra132   at mscp    drive 132
disk    ra133   at mscp    drive 133
disk    ra134   at mscp    drive 134
disk    ra135   at mscp    drive 135
disk    ra136   at mscp    drive 136
disk    ra137   at mscp    drive 137
disk    ra138   at mscp    drive 138
disk    ra139   at mscp    drive 139
```

Example 1-2: (continued)

disk	ra140	at mscp	drive 140
disk	ra141	at mscp	drive 141
disk	ra142	at mscp	drive 142
disk	ra143	at mscp	drive 143
disk	ra144	at mscp	drive 144
disk	ra145	at mscp	drive 145
disk	ra146	at mscp	drive 146
disk	ra147	at mscp	drive 147
disk	ra148	at mscp	drive 148
disk	ra149	at mscp	drive 149
disk	ra150	at mscp	drive 150
disk	ra151	at mscp	drive 151
disk	ra152	at mscp	drive 152
disk	ra153	at mscp	drive 153
disk	ra154	at mscp	drive 154
disk	ra155	at mscp	drive 155
disk	ra156	at mscp	drive 156
disk	ra157	at mscp	drive 157
disk	ra158	at mscp	drive 158
disk	ra159	at mscp	drive 159
disk	ra160	at mscp	drive 160
disk	ra161	at mscp	drive 161
disk	ra162	at mscp	drive 162
disk	ra163	at mscp	drive 163
disk	ra164	at mscp	drive 164
disk	ra165	at mscp	drive 165
disk	ra166	at mscp	drive 166
disk	ra167	at mscp	drive 167
disk	ra168	at mscp	drive 168
disk	ra169	at mscp	drive 169
disk	ra170	at mscp	drive 170
disk	ra171	at mscp	drive 171
disk	ra172	at mscp	drive 172
disk	ra173	at mscp	drive 173
disk	ra174	at mscp	drive 174
disk	ra175	at mscp	drive 175
disk	ra176	at mscp	drive 176
disk	ra177	at mscp	drive 177
disk	ra178	at mscp	drive 178
disk	ra179	at mscp	drive 179
disk	ra180	at mscp	drive 180
disk	ra181	at mscp	drive 181
disk	ra182	at mscp	drive 182
disk	ra183	at mscp	drive 183
disk	ra184	at mscp	drive 184
disk	ra185	at mscp	drive 185
disk	ra186	at mscp	drive 186
disk	ra187	at mscp	drive 187
disk	ra188	at mscp	drive 188
disk	ra189	at mscp	drive 189
disk	ra190	at mscp	drive 190
disk	ra191	at mscp	drive 191
disk	ra192	at mscp	drive 192
disk	ra193	at mscp	drive 193
disk	ra194	at mscp	drive 194
disk	ra195	at mscp	drive 195
disk	ra196	at mscp	drive 196
disk	ra197	at mscp	drive 197
disk	ra198	at mscp	drive 198
disk	ra199	at mscp	drive 199
disk	ra200	at mscp	drive 200
disk	ra201	at mscp	drive 201
disk	ra202	at mscp	drive 202

Example 1-2: (continued)

disk	ra203	at mscp	drive 203
disk	ra204	at mscp	drive 204
disk	ra205	at mscp	drive 205
disk	ra206	at mscp	drive 206
disk	ra207	at mscp	drive 207
disk	ra208	at mscp	drive 208
disk	ra209	at mscp	drive 209
disk	ra210	at mscp	drive 210
disk	ra211	at mscp	drive 211
disk	ra212	at mscp	drive 212
disk	ra213	at mscp	drive 213
disk	ra214	at mscp	drive 214
disk	ra215	at mscp	drive 215
disk	ra216	at mscp	drive 216
disk	ra217	at mscp	drive 217
disk	ra218	at mscp	drive 218
disk	ra219	at mscp	drive 219
disk	ra220	at mscp	drive 220
disk	ra221	at mscp	drive 221
disk	ra222	at mscp	drive 222
disk	ra223	at mscp	drive 223
disk	ra224	at mscp	drive 224
disk	ra225	at mscp	drive 225
disk	ra226	at mscp	drive 226
disk	ra227	at mscp	drive 227
disk	ra228	at mscp	drive 228
disk	ra229	at mscp	drive 229
disk	ra230	at mscp	drive 230
disk	ra231	at mscp	drive 231
disk	ra232	at mscp	drive 232
disk	ra233	at mscp	drive 233
disk	ra234	at mscp	drive 234
disk	ra235	at mscp	drive 235
disk	ra236	at mscp	drive 236
disk	ra237	at mscp	drive 237
disk	ra238	at mscp	drive 238
disk	ra239	at mscp	drive 239
disk	ra240	at mscp	drive 240
disk	ra241	at mscp	drive 241
disk	ra242	at mscp	drive 242
disk	ra243	at mscp	drive 243
disk	ra244	at mscp	drive 244
disk	ra245	at mscp	drive 245
disk	ra246	at mscp	drive 246
disk	ra247	at mscp	drive 247
disk	ra248	at mscp	drive 248
disk	ra249	at mscp	drive 249
disk	ra250	at mscp	drive 250
disk	ra251	at mscp	drive 251
disk	ra252	at mscp	drive 252
disk	ra253	at mscp	drive 253
disk	ra254	at mscp	drive 254
disk	rz0	at sii0	drive 0
disk	rz1	at sii0	drive 1
disk	rz2	at sii0	drive 2
disk	rz3	at sii0	drive 3
disk	rz4	at sii0	drive 4
disk	rz5	at sii0	drive 5
disk	rz6	at sii0	drive 6
disk	rz7	at sii0	drive 7
disk	rz0	at asc0	drive 0
disk	rz1	at asc0	drive 1
disk	rz2	at asc0	drive 2

Example 1-2: (continued)

disk	rz3	at asc0	drive 3
disk	rz4	at asc0	drive 4
disk	rz5	at asc0	drive 5
disk	rz6	at asc0	drive 6
disk	rz7	at asc0	drive 7
disk	rz8	at asc1	drive 0
disk	rz9	at asc1	drive 1
disk	rz10	at asc1	drive 2
disk	rz11	at asc1	drive 3
disk	rz12	at asc1	drive 4
disk	rz13	at asc1	drive 5
disk	rz14	at asc1	drive 6
disk	rz15	at asc1	drive 7
disk	rz16	at asc2	drive 0
disk	rz17	at asc2	drive 1
disk	rz18	at asc2	drive 2
disk	rz19	at asc2	drive 3
disk	rz20	at asc2	drive 4
disk	rz21	at asc2	drive 5
disk	rz22	at asc2	drive 6
disk	rz23	at asc2	drive 7
disk	rz24	at asc3	drive 0
disk	rz25	at asc3	drive 1
disk	rz26	at asc3	drive 2
disk	rz27	at asc3	drive 3
disk	rz28	at asc3	drive 4
disk	rz29	at asc3	drive 5
disk	rz30	at asc3	drive 6
disk	rz31	at asc3	drive 7
tape	tms0	at mscp	drive 0
tape	tms1	at mscp	drive 1
tape	tms2	at mscp	drive 2
tape	tms3	at mscp	drive 3
tape	tms4	at mscp	drive 4
tape	tms5	at mscp	drive 5
tape	tms6	at mscp	drive 6
tape	tms7	at mscp	drive 7
tape	tms8	at mscp	drive 8
tape	tms9	at mscp	drive 9
tape	tms10	at mscp	drive 10
tape	tms11	at mscp	drive 11
tape	tms12	at mscp	drive 12
tape	tms13	at mscp	drive 13
tape	tms14	at mscp	drive 14
tape	tms15	at mscp	drive 15
tape	tms16	at mscp	drive 16
tape	tms17	at mscp	drive 17
tape	tms18	at mscp	drive 18
tape	tms19	at mscp	drive 19
tape	tms20	at mscp	drive 20
tape	tms21	at mscp	drive 21
tape	tms22	at mscp	drive 22
tape	tms23	at mscp	drive 23
tape	tms24	at mscp	drive 24
tape	tms25	at mscp	drive 25
tape	tms26	at mscp	drive 26
tape	tms27	at mscp	drive 27
tape	tms28	at mscp	drive 28
tape	tms29	at mscp	drive 29
tape	tms30	at mscp	drive 30
tape	tms31	at mscp	drive 31
tape	tz0	at sii0	drive 0

Example 1-2: (continued)

```
tape    tz1      at sii0      drive 1
tape    tz2      at sii0      drive 2
tape    tz3      at sii0      drive 3
tape    tz4      at sii0      drive 4
tape    tz5      at sii0      drive 5
tape    tz6      at sii0      drive 6
tape    tz7      at sii0      drive 7
tape    tz0      at asc0      drive 0
tape    tz1      at asc0      drive 1
tape    tz2      at asc0      drive 2
tape    tz3      at asc0      drive 3
tape    tz4      at asc0      drive 4
tape    tz5      at asc0      drive 5
tape    tz6      at asc0      drive 6
tape    tz7      at asc0      drive 7
tape    tz8      at asc1      drive 0
tape    tz9      at asc1      drive 1
tape    tz10     at asc1      drive 2
tape    tz11     at asc1      drive 3
tape    tz12     at asc1      drive 4
tape    tz13     at asc1      drive 5
tape    tz14     at asc1      drive 6
tape    tz15     at asc1      drive 7
tape    tz16     at asc2      drive 0
tape    tz17     at asc2      drive 1
tape    tz18     at asc2      drive 2
tape    tz19     at asc2      drive 3
tape    tz20     at asc2      drive 4
tape    tz21     at asc2      drive 5
tape    tz22     at asc2      drive 6
tape    tz23     at asc2      drive 7
tape    tz24     at asc3      drive 0
tape    tz25     at asc3      drive 1
tape    tz26     at asc3      drive 2
tape    tz27     at asc3      drive 3
tape    tz28     at asc3      drive 4
tape    tz29     at asc3      drive 5
tape    tz30     at asc3      drive 6
tape    tz31     at asc3      drive 7
```

Ethernet devices

```
device  xna0 at vaxbi? node? vector xnaintr
device  xna1 at vaxbi? node? vector xnaintr
device  xna2 at vaxbi? node? vector xnaintr
device  xna3 at vaxbi? node? vector xnaintr
device  ln0  at ibus?  vector lnintr
device  ln1  at ibus?  vector lnintr
device  ln2  at ibus?  vector lnintr
device  ln3  at ibus?  vector lnintr
device  ne0  at ibus?  vector neintr
device  fza0 at ibus?  vector fzaintr
device  fza1 at ibus?  vector fzaintr
device  fza2 at ibus?  vector fzaintr
device  qe0  at uba?    csr 0174440 vector qeintr
device  qe1  at uba?    csr 0174460 vector qeintr
```

Terminal Devices

```
device  dmb0 at vaxbi? node? flags 0xff vector dmbsint dmbaint dmblint
device  dmb1 at vaxbi? node? flags 0xff vector dmbsint dmbaint dmblint
device  dmb2 at vaxbi? node? flags 0xff vector dmbsint dmbaint dmblint
device  dmb3 at vaxbi? node? flags 0xff vector dmbsint dmbaint dmblint
device  dmb4 at vaxbi? node? flags 0xff vector dmbsint dmbaint dmblint
device  dmb5 at vaxbi? node? flags 0xff vector dmbsint dmbaint dmblint
```

Example 1-2: (continued)

```
device dmb6 at vaxbi? node? flags 0xff vector dmbsint dmbaint dmblint
device dmb7 at vaxbi? node? flags 0xff vector dmbsint dmbaint dmblint
device dmb8 at vaxbi? node? flags 0xff vector dmbsint dmbaint dmblint
device dmb9 at vaxbi? node? flags 0xff vector dmbsint dmbaint dmblint
device dmb10 at vaxbi? node? flags 0xff vector dmbsint dmbaint dmblint
device dmb11 at vaxbi? node? flags 0xff vector dmbsint dmbaint dmblint
device dmb12 at vaxbi? node? flags 0xff vector dmbsint dmbaint dmblint
device dmb13 at vaxbi? node? flags 0xff vector dmbsint dmbaint dmblint
device dmb14 at vaxbi? node? flags 0xff vector dmbsint dmbaint dmblint
device dmb15 at vaxbi?node? flags 0xff vector dmbsint dmbaint dmblint
device dc0 at ibus? vector dcintr
device mdc0 at ibus? vector mdcintr
device mdc1 at ibus? vector mdcintr
device mdc2 at ibus? vector mdcintr
```

graphic devices

```
device pm0 at ibus? vector pmvint
device cfb0 at ibus? vector cfbvint
device gq0 at ibus? vector gqintr
device ga0 at ibus? vector gaintr
```

Other devices

```
device lp0 at uba? csr 0177514 vector lpintr
```

```
pseudo-device pty 64
pseudo-device inet
pseudo-device ether
pseudo-device loop
pseudo-device nfs
pseudo-device ufs
pseudo-device rpc
pseudo-device sys_trace
pseudo-device lat
pseudo-device lta 32
pseudo-device dli
pseudo-device presto
```

This chapter describes the three methods for building a kernel:

- You can build a kernel automatically, using the `doconfig` command, as described in Section 2.2.
- You can build a kernel manually, following the steps listed in Section 2.3. If you opt to build a kernel manually, make sure that you understand the contents and format of the system configuration file. Chapter 1 describes this file.
- You can build a kernel when you change the user capacity of your system, by using either the License Management Facility or the capacity upgrade installation. Section 2.4 describes this procedure.

Choose the procedure that best complements your experience and the needs of your particular installation. Should the new kernel you build fail to boot, you can use the procedure described in Section 2.5 to recover the original kernel.

Note

In this chapter there are two naming conventions:

- The string `HOSTNAME` represents the name you have assigned to your system, in uppercase letters.
- The string `{vax,mips}` or `{VAX,MIPS}` represents separate directory paths. You choose which directory path to use, depending on your machine's architecture, VAX or RISC.

2.1 When To Build a New Kernel

You need to build a new kernel after any of the following events:

- If you add a new device and its driver to your configuration. When you add a new device and device driver, you need to rebuild the kernel to include the specifications in the configuration file.
- If you remove a device and its driver from your configuration. When you remove a device and device driver from your configuration and edit the configuration file to include only the actual hardware and software at your installation, you need to rebuild the kernel to match this configuration.
- If you tune the operating system. When you alter the default configuration or change the original disk setup, you need to rebuild the kernel. For example, if you create swap areas on two disk drives, thereby modifying the original single swap area on disk, you need to rebuild the kernel.

You may need to build a new kernel after any of these events:

- If you upgrade your system. For example, if you increase the login capacity on your system through the License Management Facility or a capacity upgrade.
- If you add layered products, for example, if you add the DECnet facility, or any layered product that requires system configuration changes.

2.2 Building a Kernel Automatically

The ULTRIX software provides the `/etc/doconfig` program with which you build your kernel automatically. The following section describes this procedure.

2.2.1 Using the doconfig Program

To update an existing configuration file or create a new one using `/etc/doconfig`, the system must be operating the generic kernel, `genvmunix`.

To use the `/etc/doconfig` program, follow these steps:

1. Log in as superuser (`root`). You must be superuser to execute the `doconfig` command.
2. Shut down the system to single-user mode:

```
# /etc/shutdown +5 "Building a new kernel"
```
3. Save the running `vmunix` as `vmunix.old`:

```
# mv /vmunix /sys/vmunix.old
```
4. Copy `/genvmunix` to `/vmunix`:

```
# cp /genvmunix /vmunix
```
5. Halt the processor:

```
# /etc/halt
```
6. Reboot the system to single-user mode. Refer to the *Guide to Shutdown and Startup* for instructions (different processors have different procedures).
7. Check the file systems:

```
# /etc/fsck -p
```
8. Mount the UFS file systems:

```
# /etc/mount -a -t ufs
```
9. Start the error log:

```
# eli -s
```

The following question is displayed:

Caution: Are you in Single User Mode? (y)

Answer yes to the question; you shut down to single-user mode in step 2.

10. Run the update daemon:

```
# /etc/update
```

11. Save your existing configuration file:

```
# cd /sys/conf/{vax,mips}
# cp HOSTNAME HOSTNAME.old
```

12. Set the EDITOR environment variable to specify the text editor you want to use to edit the configuration file. For example, to use the `ex` editor, type:

```
# EDITOR=ex
# export EDITOR
```

13. Run the `doconfig` program:

```
# cd /
# /etc/doconfig
```

The `doconfig` program then prompts you for information about your system configuration.

14. Type *yes* when the `doconfig` program asks if you want to edit the configuration file. The `doconfig` program then invokes the editor specified by the EDITOR environment variable.

15. Compare your saved configuration file with the new configuration file to determine the differences (if any). You can use the editor's shell escape to compare the files. For example, if you are using the `ex` editor, type:

```
diff /sys/conf/{vax, mips}/HOSTNAME /sys/conf/{vax, mips}/HOSTNAME.old
```

16. Edit the new configuration file to include the kernel options, pseudo-devices, system parameters, or other changes you want to bring forward from the old configuration file.

Note

If you added or removed any communications devices from your configuration file you need to edit the `/etc/ttys` file to match your new configuration (that is, to match the `/dev/tty??` files).

17. Write the changes to the new configuration file and end the editing session. The `doconfig` program will build the new kernel. When the `doconfig` program finishes, it prints a message showing the path and location of the new `vmunix`. To test the new kernel, see Section 2.2.2.

Refer to `doconfig(8)` in the *ULTRIX Reference Pages* for details on the command and its options.

Example 2-1 shows a sample execution of the `doconfig` program. Entries in ([]) are the default values. To select a default value, press the Return key. The example shows the default entries typed in for presentation purposes only.

Once you enter the system name and the date and time information, the `doconfig` program builds a configuration file. Note that if you type a system name that exists, the `doconfig` program will verify that you want that system replaced. If you provide the name of a system that does not exist, you are not asked this question. When `doconfig` completes the configuration file build process, it loads `vmunix`, rearranges the symbol table, and makes the special files for the system based on the configuration.

Example 2-1: Sample `doconfig` Execution

```
# /etc/doconfig
```

Type the name of your system using alphanumeric characters.
The first character must be a letter. For example, `tinker`.

Type your system name: **tinker**

You typed `tinker` as the name of your system.
Is this correct? Type y or n [y]: **y**

A system with that name already exists. Replace it? (y/n) [y]: **y**

*** SPECIFY THE DATE AND TIME ***

Enter the current date and time in this format:
`ymmddhhmm`. Use two digits for year (`yy`),
month (`mm`), day (`dd`), hour (`hh`), and minute (`mm`).
You type the time in 24-hour format. For example,
for 11:30 p.m. on May 3, 1990, the response
would be:

```
9005032330
```

Type the date and time [no default]: **9005032330**

*** SPECIFY THE TIME ZONE INFORMATION ***

Enter the time zone for your area, using the options
listed in the table below. You can also enter the number of
hours (-12 to 12) in time east of Greenwich.

Selection	Time Zone
e	Eastern
c	Central
m	Mountain
p	Pacific
g	Greenwich

Enter your choice: **p**

Does your area alternate between Daylight Savings
and Standard time [yes] ? **yes**

Select your geographic area for Daylight Savings Time,

Example 2-1: (continued)

using the options in the table below.

Selection	Geographic Area
u	USA
a	Australia
e	Eastern Europe
c	Central Europe
w	Western Europe

Enter your choice [u]: u

Thurs May 10 12:29:00 EDT 1990

*** System Configuration Procedure ***

Configuration file complete.

Do you want to edit the configuration file? (y/n) [n]: y

< You would be editing here >

*** PERFORMING SYSTEM CONFIGURATION ***

working Sun May 13 09:40:44 EDT 1990

working Sun May 13 09:42:45 EDT 1990

*** DEVICE SPECIAL FILE CREATION ***

working Sun May 13 09:44:08 EDT 1990

A log file listing Special Device Files is located in /dev/MAKEDEV.log

The new kernel is /sys/VAX/TINKER/vmunix

2.2.2 Testing the New Kernel

On completion of the automatic configuration process, you can test the new kernel that you have built by performing the following steps:

1. Put the newly created kernel in the root directory. For instance, to put the kernel created in Example 2-1 into the root directory, you would type:

```
# mv /sys/VAX/TINKER/vmunix /vmunix
# chmod 755 /vmunix
```

2. Reboot the system:

```
# /etc/reboot
```

If you have problems booting your new kernel, you may have made errors in your configuration file. You can use the original kernel you copied to /sys/vmunix.old while you correct any errors in your new configuration file. Refer to Section 2.5 for instructions.

2.3 Building a New Kernel Manually

You can build a new kernel manually in either single-user or multi-user mode. However, it is recommended that you build it in single-user mode, so the build process is protected from users.

You can shut down the system to single-user mode with the following command:

```
# /etc/shutdown +5 "Building a new kernel"
```

To build a new kernel manually in either single-user or multi-user mode, you must perform the following steps:

1. Edit the configuration file.
2. Run the `config` utility.
3. Define code dependencies.
4. Compile and load the binary files.
5. Boot the new kernel.

Each of these steps is described in the following sections. You must follow these steps consecutively.

2.3.1 Edit the Configuration File

The configuration file resides in one of the following two directories, depending on what type of hardware you have:

- The `/sys/conf/vax` directory
- The `/sys/conf/mips` directory

The configuration file has the same name as your system, but in uppercase letters. For example, if your VAX system is named `myvax`, your configuration file is named `/sys/conf/vax/MYVAX`. If your RISC system is named `mymips`, your configuration file is named `/sys/conf/mips/MYMIPS`.

The configuration file is the file you copy and edit when you build a new kernel. This file includes definitions for all supported devices. The supported devices are listed in Appendix A.

Follow these steps to copy and then to edit the configuration file:

1. Log in to the system as superuser (`root`).
2. Change your working directory to `/sys/conf/vax` or `/sys/conf/mips` by typing one of the following commands:

```
# cd /sys/conf/vax
# cd /sys/conf/mips
```

3. Make a backup copy of the original configuration file. To do this, copy the original configuration file to another file in the same directory.

For example, if your configuration file is MYVAX, type the following:

```
# cp MYVAX MYVAX.old
```

If your configuration file is MYMIPS, type the following:

```
# cp MYMIPS MYMIPS.old
```

4. Change the file access permissions (mode) of the working configuration file to permit the owner to write to it. For example, if your working configuration file is named MYVAX, type the following:

```
# chmod +w MYVAX
```

If your working configuration file is named MYMIPS, type the following:

```
# chmod +w MYMIPS
```

5. Edit the working file. Use a text editor, such as the `vi` editor, to add or delete entries in the MYVAX or MYMIPS working configuration file. Use the format and rules described in Chapter 1 to make changes to the configuration file.

2.3.2 Run the config Utility

When you have edited the configuration file, run the `config` utility to create directories in which to store binary files.

Follow these steps to generate the new directories:

1. Make sure that your working directory is either `/sys/conf/vax` or `/sys/conf/mips`. (You should be in this directory after editing the configuration file.)
2. Run the `config` utility with the name of the working configuration file you edited in Section 2.3.1. For example, if your configuration file is named MYVAX, issue the following command:

```
# config MYVAX
```

Don't forget to run "make depend"

If your configuration file is named MYMIPS, issue the following command:

```
# config MYMIPS
```

Don't forget to run "make depend"

The utility creates a directory with the same name as your configuration file, if it does not already exist. For example, if your system is a VAX system and your configuration file is named MYVAX, the `config` utility creates the directory `/sys/VAX/MYVAX`. If your system is a RISC system and your configuration file is named MYMIPS, the `config` utility creates the directory `/sys/MIPS/MYMIPS`. When the utility finishes creating the directory, it displays a message to remind you to execute the `make` command with the `depend` parameter. For more information, see `make(1)` in the *ULTRIX Reference Pages*.

2.3.3 Define the Code Dependencies

Your next step is to define the code dependencies. The code dependencies determine which binary files are needed and how they are built, based on the configuration of your kernel.

To define the code dependencies:

1. Change your working directory to directory `config` created in Section 2.3.2. For example, if your system configuration file is named `MYVAX`, issue the following command:

```
# cd /sys/VAX/MYVAX
```

If your system configuration file is named `MYMIPS`, issue the following command:

```
# cd /sys/MIPS/MYMIPS
```

2. Execute the `make` command with the `clean` parameter. The following example shows how to issue this command:

```
# make clean
```

This command ensures that the `/sys/VAX/MYVAX` directory or the `/sys/MIPS/MYMIPS` directory contains only the required files for creating the kernel specified by the `MYVAX` or the `MYMIPS` configuration file.

3. Execute the `make` command with the `depend` parameter, as shown in the following example:

```
# make depend
```

This command instructs `make` to build or rebuild the rules that it needs to recognize interdependencies in the system source code. Executing this command ensures that any changes to the system source code will be recompiled the next time you run the `make` command. The `make` command modifies the `makefile`, appending the dependencies to the end of the file.

2.3.4 Compile and Load the Binary Files

After defining the code dependencies, compile and load the new binary files, using the `makefile` that you just created.

To compile and load the binary files:

1. Use the `make` command to produce a complete binary system image, the kernel. The kernel is stored in the current directory. The system responds by displaying a number of messages as it compiles and loads the binary files. When the `make` command completes this task, the system redisplay the system prompt.

The following example shows how to issue the `make` command (the output from the command may be different from what is shown here):

```
# make
/bin/rm -f a.out a.out.q assym.h
.
.
#
```

2. If the system is in multiuser mode, you must now shut it down to single-user

mode, by typing the following:

```
# /etc/shutdown +5 "Building a new kernel"
```

3. Because you may have made errors in your configuration file, it is recommended that you save the original kernel. If the new kernel fails, you can recover by booting from the generic kernel, `/genvmunix`, and correct any errors in your configuration file. Move the original kernel to another filename. The following example shows how to move the kernel:

```
# mv /vmunix /sys/vmunix.old
```

4. The output of the `make` command is a kernel named `vmunix` in the current directory. Move this file to the root directory and then change its mode. For example:

```
# mv vmunix /vmunix
# chmod 755 /vmunix
```

/usr/sys/mips/dose1
~~~~~
~~~~~

The original `/vmunix` file is replaced by the new `vmunix` file and is ready to be booted. The original `/vmunix` resides in `/sys/vmunix.old` because you copied it there in step 3.

2.3.5 Boot the New Kernel

Use the `reboot` command to boot the new kernel, `/vmunix`. To boot the new kernel, type:

```
# /etc/reboot
```

In this example, the processor halts and then automatically reboots using the default boot device. The system boots the `/vmunix` image.

If the new kernel fails to boot or displays errors, you can recover by booting the original kernel, `vmunix.old`, and running that kernel until you determine the cause of the problem. Refer to Section 2.5 for instructions.

2.4 Building a Kernel After a Capacity Upgrade Installation

If you installed a larger user capacity License Management Facility (LMF) key, or plan to use a capacity upgrade, you may need to increase the maximum number of users to match this capacity, and then build a new kernel.

Set the `maxusers` parameter in the configuration file to equal the number of authorized users in your capacity upgrade installation kit or in your License Management Facility PAK. If your capacity is unlimited, then set `maxusers` to match the maximum number of simultaneous user logins.

To determine the current value of `maxusers`, type the following:

```
# grep maxusers /sys/conf/{vax,mips}/HOSTNAME
```

Use the following procedure to increase `maxusers` and build a new kernel (if necessary):

1. Log in as superuser (`root`).
2. Set the `EDITOR` environment variable to specify the text editor you want to use

to edit the configuration file. For example, to use the `ex` editor, type:

```
# EDITOR=ex
# export EDITOR
```

3. Execute the `doconfig` program with the `-c` option to build a new kernel from your existing configuration file:

```
# /etc/doconfig -c HOSTNAME
```

4. Type `yes` when the `doconfig` program asks if you want to edit the configuration file. Then, `doconfig` calls your default editor, so you can use it to change the `maxusers` parameter to the new number of authorized users. For example, if you have an upgrade installation kit for 64 users, the new entry would be:

```
maxusers 64
```

5. Exit from the editor; the `doconfig` program then resumes running and builds the new kernel.

6. Shut down the system to single-user mode:

```
# /etc/shutdown +5 "Installing new kernel"
```

7. Save the running `vmunix` kernel as `vmunix.old`:

```
# mv /vmunix /sys/vmunix.old
```

8. Put the newly created kernel into the root directory:

```
# mv /sys/{VAX,MIPS}/HOSTNAME/vmunix /vmunix
# chmod 755 /vmunix
```

9. Reboot the system:

```
# /etc/reboot
```

If you have problems booting the new kernel, refer to Section 2.5 for instructions on how to recover your original kernel.

2.5 How to Recover When a New Kernel Fails to Boot

If you have problems booting your new kernel, use the following procedure to recover the original kernel, `vmunix.old`:

1. Boot the generic kernel to single-user mode. Refer to the *Guide to Shutdown and Startup* for instructions on how to boot your processor. You use a conversational mode boot to boot the generic kernel `/genvmunix`.

2. Check your file systems:

```
# /etc/fsck -p
```

3. Mount your local file systems:

```
# /etc/mount -a -t ufs
```

4. Copy the original kernel to the root directory:

```
# cp /sys/vmunix.old /vmunix
```

5. Reboot the system:

```
# /etc/reboot
```

Device Mnemonics

A

This appendix identifies and defines the mnemonics that are used to attach any hardware or software device to your system. The mnemonics are used by the `/dev/MAKEDEV` shell script to create the character or block special files that represent each of the devices. The mnemonics also appear in the system configuration file.

Table A-1 lists the mnemonics in nine categories: generic, systems, consoles, disks, tapes, terminals, modems, printers, and others. The generic category lists the mnemonics of a general nature and includes memory, null, trace, and tty devices. The systems category lists the mnemonic for the DECstation 3100 system setup. The consoles category lists the system console devices that the ULTRIX operating system uses. The disks, tapes, terminals, modems, and printers categories identify the appropriate mnemonics for those devices. The others category lists the mnemonic for DECstation 3100 devices.

The *description heading* in Table A-1 identifies the corresponding device name. It does not define the mnemonic's use. For detailed information on the use of each mnemonic in relation to both the MAKEDEV script and the system configuration file, refer to the reference pages in Section 4 of the *ULTRIX Reference Pages*. If on-line reference pages are available, you can also use the `man` command. For instance, enter the following command at the system prompt to display the reference page for the Small Computer System Interconnect (SCSI) disk controller driver:

```
% man rz
```

Where appropriate, the SYNTAX section of the reference page defines the device's syntax as it should appear, in the `config` file. Refer to `/dev/MAKEDEV` for additional software device mnemonics that MAKEDEV uses. Refer to MAKEDEV(8) in the *ULTRIX Reference Pages* for a description of the MAKEDEV utility.


Table A-1 uses the convention of an asterisk (*) beside a mnemonic and a question mark (?) beside a device name to mean a variable number. The value of the variable number is dependent on the particular device.

Table A-1: Devices Supported by MAKEDEV

Category	Mnemonic	Description
Generic	boot*	Boot and std devices by cpu number; for example, boot750
	mvax*	All MicroVAX setups; for example, mvax2000
	vaxstation*	A VAXstation 2000 setup; for example, vaxstation2000
	std	Standard devices with all console subsystems
	drum	Kernel drum device
	errlog	Error log device
	audit	Audit log device
	kUmem	Kernel Unibus/Q-bus virtual memory
	kmem	Virtual main memory
	mem	Physical memory
	null	A null device
	trace	A trace device
	tty	A character terminal device
	local	Customer-specific devices
Systems	DECstation	A DECstation 3100 setup
Consoles	console	System console interface
	crl	Console RL02 disk interface for VAX 86?0
	cs*	Console RX50 floppy interface for VAX 8??0
	ctu*	Console TU58 cassette interface for VAX 11/725/730/750
	cty*	Console extra serial line units for VAX 8??0
	cfi	Console RX01 floppy interface for 11/78?
	ttycp	Console line used as auxiliary terminal port
Disks	hp*	MASSBUS disk interface for RM?? drives and RP?? devices
	ra*	UNIBUS/Q-bus/BI/HSC/DSSI MSCP disk controller interface
	rb*	UNIBUS IDC RL02 disk controller interface for RB?? drives
	rd*	VAXstation 2000 and MicroVAX 2000 RD type drives
	rz	SCSI disks (for example, the RZ56)
	rk*	UNIBUS RK?? disk controller interface
	rl*	UNIBUS/Q-bus RL?? disk controller interface
	rx*	VAXstation 2000 and MicroVAX 2000 RX type drives
Tapes	mu*	MASSBUS magtape interface (for example, the TU78)
	tms*	UNIBUS/Q-bus/BI/HSC/DSSI TMSCP tape controller interface
	rv*	UNIBUS/Q-bus/BI TMSCP optical disk
	ts*	UNIBUS/Q-bus TS11/TS05/TU80 magtape interface
	tu*	TE16/TU45/TU77 MASSBUS magtape interface
	st*	VAXstation 2000 and MicroVAX 2000 TZK50 cartridge tape
	tz*	SCSI tapes (for example, the TZU50)
Terminals	cx*	Q-bus cxa16
	cx*	Q-bus cxb16
	cx*	Q-bus cxt08
	dfa*	Q-bus DFA01 comm multiplexer
	dhq*	Q-bus DHQ11 comm multiplexer
	dhu*	UNIBUS DHU11 comm multiplexer
	dhv*	Q-bus DHV11 comm multiplexer
	dmb*	BI DMB32 comm multiplexer including dmbsp serial printer/plotter
	dmb*	BI DMB32 comm multiplexer
	dhb*	BI DHB32 comm multiplexer

Table A-1: (continued)

Category	Mnemonic	Description
	dmf*	UNIBUS DMF32 comm multiplexer including dmfsp serial printer/plotter
	dmz*	UNIBUS DMZ32 comm multiplexer
	dz	UNIBUS DZ11 and DZ32 comm multiplexer
	sh*	MicroVAX 2000, 8 serial line expansion option
	ss*	VAXstation 2000 and MicroVAX 2000 basic 4 serial line unit
	fc*	VAXstation 60 basic 4 serial line unit
	dzq*	Q-bus DZQ11 comm multiplexer
	dzv*	Q-bus DZV11 comm multiplexer
	lta*	Sets of 16 network local area terminals (LAT)
	pty*	Sets of 16 network pseudoterminals
	qd*	Q-bus VCB02 (QDSS) graphics controller/console
	qv*	Q-bus VCB01 (QVSS) graphics controller/console
	sm*	VAXstation 2000 monochrome bitmap graphics/console
	sg*	VAXstation 2000 color bitmap graphics console
	lx	VAXstation 8000 color high-performance 3D graphics
	fg*	VAXstation 60 color bitmap graphics/console
Modems	dfa*	DFA01 integral modem communications device.
Printers	dmbsp*	BI DMB32 serial printer/plotter
	dmfsp*	UNIBUS DMF32 serial printer/plotter
	lp*	UNIBUS LP11 parallel line printer
	lpv*	Q-bus LP11 parallel line printer
Packet filter	pfilt	Packet filter devices; set of 64
Other	pm*	mono/color bitmap graphics/mouse/modem /printer/terminals for DECstation 3100



A

attachable address

specifying in configuration file, 1-6

AUDIT option

specifying in configuration file, 1-8

audit pseudodevice definition

specifying in configuration file, 1-17

B

bsc pseudodevice definition

specifying in configuration file, 1-16

bufcache parameter

specifying in configuration file, 1-5

byte order

specifying in configuration file, 1-8

C

capacity upgrade installation

rebuilding the kernel after, 2-9

CI adapters

specifying in configuration file, 1-11

configuration file

accessing the NFS protocol, 1-8

allocating virtual memory, 1-5

allowing multiple processors to run, 1-8

assigning root partition, 1-9

defining a driver for pseudodevice, 1-16

description, 1-1

device definitions

specifying adapters, 1-10

device specifications, 1-14

editing, 2-6

enabling access from a local area network, 1-7

configuration file (cont.)

enabling DECNET, 1-7

enabling disk quotas, 1-7

enabling emulation of floating point, 1-7

enabling ethernet communications, 1-7

enabling full dumps, 1-7

enabling local file system, 1-8

enabling mop_mom program, 1-8

enabling RPC-based applications, 1-8

enabling system call tracing, 1-8

enabling trusted path mechanism, 1-8

estimating physical memory, 1-5

format, 1-1

generic template, 1-2

loading optional audit subsystem, 1-8

location of, 1-1

makeoptions

specifying byte order, 1-8

master specifications, 1-11 to 1-12

options, 1-7

specifying AUDIT, 1-8

specifying DECNET, 1-7

specifying DLI, 1-8

specifying EMULFLT, 1-7

specifying FULLDUMPS, 1-7

specifying INET, 1-7

specifying LAT, 1-7

specifying NFS, 1-8

specifying QUOTA, 1-7

specifying RPC, 1-8

specifying SMP, 1-8

specifying SYS_TPATH, 1-8

specifying SYS_TRACE, 1-8

specifying UFS, 1-8

configuration file (cont.)

- RISC example, 1-27 to 1-36
- specifying 10..MB ethernet, 1-16
- specifying 2780/3780 emulation support, 1-16
- specifying adapters, 1-11
- specifying attachable address, 1-6
- specifying audit support, 1-17
- specifying blocks of virtual memory, 1-6
- specifying CI adapters, 1-11
- specifying controllers, 1-12 to 1-14
- specifying cpu, 1-3
- specifying DARPA Internet protocols, 1-16
- specifying data segment, 1-5
- specifying DECNET support, 1-16
- specifying device definitions, 1-10 to 1-16
- specifying dump area, 1-10
- specifying global definitions, 1-2 to 1-8
- specifying IBUS adapter, 1-11
- specifying LAT protocols, 1-16
- specifying local file system support, 1-17
- specifying machine, 1-3
- specifying maximum processes, 1-4
- specifying maximum users, 1-4
- specifying minimum blocks of virtual memory, 1-6
- specifying mopmom support, 1-16
- specifying MSI adapters, 1-11
- specifying network loopback interface, 1-16
- specifying NFS support, 1-17
- specifying number of processors, 1-7
- specifying optional code, 1-7
- specifying paging area, 1-9
- specifying physical memory, 1-5
- specifying Prestoserve support, 1-16
- specifying pseudodevice definitions, 1-16 to 1-17
- specifying pseudoterminal driver, 1-16
- specifying pseudoterminal support, 1-16
- specifying Q-bus adapter, 1-11
- specifying remote procedure call facility, 1-17
- specifying SCSI controllers, 1-13
- specifying shared memory segments, 1-6
- specifying size of user virtual address, 1-5
- specifying spacing of data space, 1-6
- specifying stack segment, 1-6
- specifying swap area, 1-9

configuration file (cont.)

- specifying system call trace support, 1-16
- specifying system communications services support, 1-17
- specifying system image definitions, 1-9 to 1-10
- specifying system name, 1-4
- specifying sys_tpath support, 1-17
- specifying text segment, 1-5
- specifying time zone, 1-4
- specifying TMSCP tapes controllers, 1-13
- specifying UNIBUS adapter, 1-11
- VAX example, 1-17 to 1-26

controller specifications

- in configuration file, 1-12
- MSCP disks, 1-12
- TMSCP tapes, 1-13

CPU

- specifying in configuration file, 1-3

cpu parameter

- specifying in configuration file, 1-3

D**data segment**

- specifying in configuration file, 1-5

daylight saving time

- specifying, 1-4

DECNET option

- specifying in configuration file, 1-7

decnet pseudodevice definition

- specifying in configuration file, 1-16

device mnemonics, A-1 to A-3

- reference list, A-2t to A-3t
- using with MAKEDEV, A-1
- using with man command, A-1

DLI option

- specifying in configuration file, 1-8

dli pseudodevice definition

- specifying in configuration file, 1-16

doconfig command

- building kernel automatically, 2-2

dump device

- specifying in configuration file, 1-10

E

EMULFLT option

specifying in configuration file, 1-7

ether pseudodevice definition

specifying in configuration file, 1-16

F

FULLDUMPS option

specifying in configuration file, 1-7

G

global definition

allocating virtual memory, 1-5
estimating physical memory, 1-5
specifying attachable address, 1-6
specifying blocks of virtual memory, 1-6
specifying cpu, 1-3
specifying data segment, 1-5
specifying in configuration file, 1-2 to 1-8
specifying machine, 1-3
specifying maximum processes, 1-4
specifying maximum users, 1-4
specifying minimum blocks of virtual memory, 1-6
specifying number of processors, 1-7
specifying physical memory, 1-5
specifying shared memory segments, 1-6
specifying size of user virtual address, 1-5
specifying spacing of data space, 1-6
specifying stack segment, 1-6
specifying system name, 1-4
specifying text segment, 1-5
specifying time zone, 1-4

I

IBUS adapter

specifying in configuration file, 1-11

ident parameter

specifying in configuration file, 1-4

INET option

specifying in configuration file, 1-7

inet pseudodevice definition

specifying in configuration file, 1-16

installation

and the generic configuration file, 1-2

K

kernel

adding a device, 2-1
adding layered products, 2-1
and the system configuration file, 1-1
booting, 2-9
building, 1-1, 2-10
building automatically, 2-2 to 2-5
building manually, 2-6 to 2-9
building using doconfig, 2-2 to 2-5
compiling and loading binary files, 2-8
configuring, 1-1
defining code dependencies, 2-7
deleting a device, 2-1
execution, 2-4e to 2-5e
storing binaries, 2-7
testing, 2-5
tuning the operating system, 2-1
upgrading system, 2-1
using config, 2-7
when to rebuild, 2-1

L

LAT option

specifying in configuration file, 1-7

lat pseudodevice definition

specifying in configuration file, 1-16

loop pseudodevice definition

specifying in configuration file, 1-16

lta pseudodevice definition

specifying in configuration file, 1-16

M

machine parameter

specifying in configuration file, 1-3

MASSBUS adapter
 specifying in configuration file, 1-11

MASSBUS controller
 specifying in configuration file, 1-11

maxdsiz parameter
 specifying in configuration file, 1-5

maximum processes
 specifying in configuration file, 1-4

maximum users
 specifying in configuration file, 1-4

maxssiz parameter
 specifying in configuration file, 1-6

maxtsiz parameter
 specifying in configuration file, 1-5

maxuprc parameter
 specifying in configuration file, 1-4

maxusers parameter
 specifying in configuration file, 1-4

maxuva parameter
 specifying in configuration file, 1-5

MSCP disk controller
 specifying, 1-12e

MSI adapters
 specifying in configuration file, 1-11

N

NFS option
 specifying in configuration file, 1-8

nfs pseudodevice definition
 specifying in configuration file, 1-17

P

paging area
 specifying in configuration file, 1-9

parameter
 specifying in configuration file

- bufcache, 1-5
- cpu, 1-3
- ident, 1-4
- machine, 1-3
- maxdsize, 1-5
- maxssiz, 1-6

parameter (cont.)
 specifying in configuration file (cont.)

- maxtsiz, 1-5
- maxuprc, 1-4
- maxusers, 1-4
- maxuva, 1-5
- physmem, 1-5
- processors, 1-7
- scs_sysid, 1-7
- smbkr, 1-6
- smmax, 1-6
- smseg, 1-6
- smsmat, 1-6
- ssmin, 1-6
- swapfrag, 1-5
- timezone, 1-4

physical memory
 estimating in configuration file, 1-5
 specifying in configuration file, 1-5

physmem parameter
 specifying in configuration file, 1-5

presto pseudodevice definition
 specifying in configuration file, 1-16

printer
 specifying line width, 1-15

processor
 defining in configuration file, 1-3

processors parameter
 specifying in configuration file, 1-7

pseudodevice
 in configuration file, 1-16

pseudodevice definition
 specifying in configuration file

- audit, 1-17, 1-16 to 1-17
- bsc, 1-16
- decnet, 1-16
- dli, 1-16
- ether, 1-16
- inet, 1-16
- lat, 1-16
- loop, 1-16
- lta, 1-16
- nfs, 1-17
- presto, 1-16

pseudodevice definition (cont.)

specifying in configuration file (cont.)

pty, 1-16

rpc, 1-17

scsnet, 1-17

sys_tpath, 1-17

sys_trace, 1-16

ufs, 1-17

pty pseudodevice definition

specifying in configuration file, 1-16

Q

Q-bus adapter

specifying in configuration file, 1-11

QUOTA option

specifying in configuration file, 1-7

R

root device

specifying in configuration file, 1-9

RPC option

specifying in configuration file, 1-8

rpc pseudodevice definition

specifying in configuration file, 1-17

S

SCSI controller

specifying, 1-13e

specifying in configuration file, 1-13

scsnet pseudodevice definition

specifying in configuration file, 1-17

scs_sysid parameter

specifying in configuration file, 1-7

shared memory segment

specifying minimum size of virtual memory, 1-6

shared memory segments

specifying attachable address, 1-6

specifying in configuration file, 1-6

smbmk parameter

specifying in configuration file, 1-6

smmax parameter

specifying in configuration file, 1-6

SMP option

specifying in configuration file, 1-8

smseg parameter

specifying in configuration file, 1-6

smsmat parameter

specifying in configuration file, 1-6

ssmin parameter

specifying in configuration file, 1-6

stack segment

specifying in configuration file, 1-6

swap area

specifying in configuration file, 1-9

swapfrag parameter

specifying in configuration file, 1-5

system image definition

specifying dump device, 1-10

specifying in configuration file, 1-9 to 1-10

specifying paging area, 1-9

specifying root partition, 1-9

specifying swap area, 1-9

system name

specifying in configuration file, 1-4

SYS_TPATH option

specifying in configuration file, 1-8

sys_tpath pseudodevice definition

specifying in configuration file, 1-17

SYS_TRACE option

specifying in configuration file, 1-8

sys_trace pseudodevice definition

specifying in configuration file, 1-16

T

text segment

specifying in configuration file, 1-5

time zone

specifying in configuration file, 1-4

timezone parameter

specifying in configuration file, 1-4

TMSCP tape controller

specifying, 1-13e

U

UFS option

specifying in configuration file, 1-8

ufs pseudodevice definition

specifying in configuration file, 1-17

UNIBUS adapter

specifying in configuration file, 1-11

user virtual address

specifying size in configuration file, 1-5

V

VAX BI adapter

specifying in configuration file, 1-11

virtual memory

allocating in configuration file, 1-5

specifying in configuration file, 1-6

virtual memory blocks

specifying in configuration file, 1-6

How to Order Additional Documentation

Technical Support

If you need help deciding which documentation best meets your needs, call 800-343-4040 before placing your electronic, telephone, or direct mail order.

Electronic Orders

To place an order at the Electronic Store, dial 800-234-1998 using a 1200- or 2400-baud modem from anywhere in the USA, Canada, or Puerto Rico. If you need assistance using the Electronic Store, call 800-DIGITAL (800-344-4825).

Telephone and Direct Mail Orders

Your Location	Call	Contact
Continental USA, Alaska, or Hawaii	800-DIGITAL	Digital Equipment Corporation P.O. Box CS2008 Nashua, New Hampshire 03061
Puerto Rico	809-754-7575	Local Digital Subsidiary
Canada	800-267-6215	Digital Equipment of Canada Attn: DECdirect Operations KAO2/2 P.O. Box 13000 100 Herzberg Road Kanata, Ontario, Canada K2K 2A6
International	_____	Local Digital subsidiary or approved distributor
Internal*	_____	SSB Order Processing - WMO/E15 <i>or</i> Software Supply Business Digital Equipment Corporation Westminster, Massachusetts 01473

* For internal orders, you must submit an Internal Software Order Form (EN-01740-07).

Reader's Comments

ULTRIX
Guide to Configuration File Maintenance
AA-ME90D-TE

Please use this postage-paid form to comment on this manual. If you require a written reply to a software problem and are eligible to receive one under Software Performance Report (SPR) service, submit your comments on an SPR form.

Thank you for your assistance.

Please rate this manual:

	Excellent	Good	Fair	Poor
Accuracy (software works as manual says)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Completeness (enough information)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Clarity (easy to understand)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Organization (structure of subject matter)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Figures (useful)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Examples (useful)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Index (ability to find topic)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Page layout (easy to find information)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

What would you like to see more/less of? _____

What do you like best about this manual? _____

What do you like least about this manual? _____

Please list errors you have found in this manual:

Page	Description
_____	_____
_____	_____
_____	_____
_____	_____

Additional comments or suggestions to improve this manual:

What version of the software described by this manual are you using? _____

Name/Title _____ Dept. _____
Company _____ Date _____
Mailing Address _____
_____ Email _____ Phone _____

----- Do Not Tear - Fold Here and Tape -----

digital™



NO POSTAGE
NECESSARY
IF MAILED IN THE
UNITED STATES

BUSINESS REPLY MAIL

FIRST-CLASS MAIL PERMIT NO. 33 MAYNARD MA

POSTAGE WILL BE PAID BY ADDRESSEE

DIGITAL EQUIPMENT CORPORATION
OPEN SOFTWARE PUBLICATIONS MANAGER
ZKO3-3/Y32
110 SPIT BROOK ROAD
NASHUA NH 03062-2698



----- Do Not Tear - Fold Here -----

Cut
Along
Dotted
Line

Reader's Comments

ULTRIX
Guide to Configuration File Maintenance
AA-ME90D-TE

Please use this postage-paid form to comment on this manual. If you require a written reply to a software problem and are eligible to receive one under Software Performance Report (SPR) service, submit your comments on an SPR form.

Thank you for your assistance.

Please rate this manual:

	Excellent	Good	Fair	Poor
Accuracy (software works as manual says)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Completeness (enough information)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Clarity (easy to understand)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Organization (structure of subject matter)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Figures (useful)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Examples (useful)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Index (ability to find topic)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Page layout (easy to find information)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

What would you like to see more/less of? _____

What do you like best about this manual? _____

What do you like least about this manual? _____

Please list errors you have found in this manual:

Page	Description
_____	_____
_____	_____
_____	_____
_____	_____
_____	_____

Additional comments or suggestions to improve this manual:

What version of the software described by this manual are you using? _____

Name/Title _____ Dept. _____


Company _____ Date _____

Mailing Address _____

_____ Email _____ Phone _____

Do Not Tear - Fold Here and Tape

digital™



NO POSTAGE
NECESSARY
IF MAILED IN THE
UNITED STATES



BUSINESS REPLY MAIL
FIRST-CLASS MAIL PERMIT NO. 33 MAYNARD MA

POSTAGE WILL BE PAID BY ADDRESSEE

DIGITAL EQUIPMENT CORPORATION
OPEN SOFTWARE PUBLICATIONS MANAGER
ZK03-3/Y32
110 SPIT BROOK ROAD
NASHUA NH 03062-2698



Do Not Tear - Fold Here

Cut
Along
Dotted
Line