CUSTOMER SERVICE BULLETIN

Radio Shaek®

Bulletin No. 491Ø-23

Description TRSDOS

Model

Model II

Stock No.

26-4910 Version 2.0a

Date

Feb. 12, 1982

Page 1 of

400 Atrium-One Tandy Center, Fort Worth, Texas 76102

Problem

In some unattended modes of operation, it is desirable to have HOST start up without any operator prompt for either enabling or disabling the remote <BREAK> key. Below are some optional patches for TRSDOS 2.0a which, when applied, will allow the HOST function to start-up without either displaying the question "Disable remote <BREAK> key (Y/N)" or requiring the operator's reply.

When the first patch is applied, the remote <BREAK> key is automatically enabled at start up; if the second patch is applied instead, HOST starts with the remote <BREAK> key disabled.

Solution

To Enable the remote <BREAK> key:

PATCH SYSTEM64 R=25 B=22 F=21D9F5ØE C=Ø6ØØ1818 (for 64K HOST) PATCH SYSTEM32 R=25 B=22 F=21D975ØE C=Ø6ØØ1818 (for 32K HOST)

To Disable the remote <BREAK> key:

PATCH SYSTEM64 R=25 B=22 F=21D9F5ØE C=Ø6Ø11818 (for 64K HOST) PATCH SYSTEM32 R=25 B=22 F=21D975ØE C=Ø6Ø11818 (for 32K HOST)