## **CUSTOMER SERVICE BULLETIN**

## Radio Shaek CUSTOMER SERVICE BULLETIN

**Builetin No.** 61Ø5-Ø5

**Description TRSDOS 16** 

Model II/16

**Stock No.** 26-6105 Version 4.1

Date July 13, 1982

Page 1 of 1

400 Atrium—One Tandy Center, Fort Worth, Texas 76102

## **Problem**

In some unattended modes of operation, it is desirable to have HOST start up without prompting the operator to enable or disable the remote <BREAK> key. Listed below are some optional patches to TRSDOS 4.1 which, when applied, will allow the HOST function to start up without displaying the "Disable remote <BREAK> key (Y/N)" or requiring the operator's reply.

\* \* \* THESE PATCHES ARE OPTIONAL! \* \* \*

## Solution

When the first patch is applied, the remote <BREAK> is automatically enabled at start up. If the second patch is applied instead of the first, HOST starts with the remote <BREAK> key disabled.

To enable the remote <BREAK> key:

PATCH SYSTEM/SYS R=110

B=213 F=2158F5ØE C=Ø6ØØ1818

To disable the remote <BREAK> key:

PATCH SYSTEM/SYS R=110

B=213 F=2158F5ØE C=Ø6Ø11818

The above patches are for the 64K HOST.